

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRIPLICATE*
(Other instructions on re-
verse side)

Form approved.
Budget Bureau No. 42-R1424.

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	5. LEASE DESIGNATION AND SERIAL NO. 030132 (a)
2. NAME OF OPERATOR Cities Service Oil Company	6. IF INDIAN, ALLOTTEE OR TRIBE NAME -
3. ADDRESS OF OPERATOR P.O. Box 69 - Hobbs, New Mexico	7. UNIT AGREEMENT NAME -
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface 2310' FSL & 1650 FEL of Section 6-T22S-R36E Lea County, New Mexico	8. FARM OR LEASE NAME Closson
	9. WELL NO. 1
	10. FIELD AND POOL, OR WILDCAT Jalmat
	11. SEC., T. R., M., OR BLK. AND SURVEY OR AREA Sec. 6-T22S-R36E
14. PERMIT NO.	15. ELEVATIONS (Show whether DF, RT, GR, etc.) 3568' DF
	12. COUNTY OR PARISH Lea
	13. STATE New Mexico

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other) PB & Recomplete in U. Yates & L. Tansill

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANS

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

We propose to do the following:

1. Kill well w/water & pull 2" tubing.
2. Set packer @ 3400 and test old Perfs. 3352-3393.
3. If water-free commercial gas is found, pull packer and set permanent plug @ 3400 and recomplete from old Perfs.
4. If water production is excessive, set retainer @ 3345 and squeeze Perfs. (3352-3393) w/200 sacks cement.
5. Pull tubing & Perf 3302-3326 & 3330-3350 w/1 hole per ft.
6. Sand water frac w/20,000 gals + 20,000# sand.
7. Run tubing to 3330 w/packer @ 3200.
8. Swab well in and flow test new perforations.

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE District Clerk

DATE 9-23-64

(This space for Federal or State office use)

APPROVED BY

TITLE

APPROVED

DATE

CONDITIONS OF APPROVAL, IF ANY:

SEP 23 1964

*See Instructions on Reverse Side
GORDON
ACTING DISTRICT ENGINEER