

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease
State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.
B-1506

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator Atlantic Richfield Company	8. Farm or Lease Name State 157 "B"
3. Address of Operator P. O. Box 1710, Hobbs, New Mexico 88240	9. Well No. 1
4. Location of Well UNIT LETTER C 330 FEET FROM THE North LINE AND 2310 FEET FROM THE West LINE, SECTION 7 TOWNSHIP 22S RANGE 36E NMPM.	10. Field and Pool, or Wildcat Jalmat Gas
15. Elevation (Show whether DF, RT, GR, etc.) 3603' GR	12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT J38 <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

TD 3830', PBD 3685'. Presently completed from Jalmat Gas perms 3430-3638'. CIBP @ 3685'.
13" OD 45# csg set @ 272' & cmtd w/200 sx.
9-5/8" OD 45# csg set @ 1620' & cmtd w/400 sx.
7" OD 24# csg set @ 3754' & cmtd w/250 sx.
2-3/8" OD tbq & Guiberson L-30 pkr set @ 3385' w/SN above pkr.
Producing zones in this well have been depleted and no other recompletion possibilities exist.
Propose to P&A in the following manner:
1. Rig up, kill well, install BOP & pull out of hole w/tbg, SN & pkr.
2. Run 2-3/8" OD EUE tbq OE to 3650' & spot 10 sx Cl C cmt (35' plug) on top of BP @ 3685'.
3. Fill hole w/heavy gelled mud between all cmt plugs.
4. Pull tbq up & spot 40 sx Cl C cmt (225' plug) across Jalmat perms 3430-3638'.
5. Pull tbq up & spot 20 sx Cl C cmt (100' plug) across top of salt @ 1712'.
6. Pull tbq up & spot 10 sx Cl C cmt @ surface, install regulation dry hole marker, clean & level location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED [Signature] TITLE Dist. Drlg. Supv. DATE 11/19/75

APPROVED BY _____ TITLE _____ DATE _____
CONDITIONS OF APPROVAL, IF ANY: