

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
<b>NM 2A</b>	

## SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		7. Unit Agreement Name
2. Name of Operator <b>Texas Pacific Oil Company, Inc.</b>		8. Farm or Lease Name <b>State "A" A/c-2</b>
3. Address of Operator <b>P. O. Box 1069, Hobbs, New Mexico 88240</b>		9. Well No. <b>50</b>
4. Location of Well UNIT LETTER <b>A</b> , <b>660</b> FEET FROM THE <b>North</b> LINE AND <b>660</b> FEET FROM <b>East</b> <b>9</b> LINE, SECTION <b>22-8</b> TOWNSHIP <b>36-E</b> RANGE <b>36-E</b> NMPM.		10. Field and Pool, or Wildcat <b>South Eunice</b>
15. Elevation (Show whether DF, RT, GR, etc.) <b>3581' DF</b>		12. County <b>Lea</b>

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input checked="" type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Move in and rig up. Install BOP.
2. Pulled rods, pump and tubing. Log 3000' to 3808'.
3. Set CIBP at 3783'.
4. Perf 3655-69-82-97-3704-18-33-48-64-71'.
5. Acidize perfs with 1500 gal. 15% NE with packer at 3776.
6. Frac with 5000 gal. pad, 20,000 gal. gel 9# brine plus 30,000# 2/0/40 sand. Flush.
7. Run tubing, pump and rods. Test.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED	TITLE <b>Area Production Foreman</b>	DATE <b>Sept. 29, 1970</b>
APPROVED BY	TITLE <b>SUPERVISOR</b>	DATE <b>OCT 1 1970</b>
CONDITIONS OF APPROVAL, IF ANY:		

RECEIVED

SEP 30 1970

OIL CONSERVATION COMM.  
HOBBS, N. M.