

NEW MEXICO OIL CONSERVATION COMMISSION

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
157	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER- <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator Atlantic Richfield Company	8. Farm or Lease Name State 157 "A"
3. Address of Operator P. O. Box 1710, Hobbs, New Mexico 88240	9. Well No. 2
4. Location of Well UNIT LETTER <u>J</u> <u>1980</u> FEET FROM THE <u>South</u> LINE AND <u>1980</u> FEET FROM THE <u>East</u> LINE, SECTION <u>9</u> TOWNSHIP <u>22S</u> RANGE <u>36E</u> N.M.P.M.	10. Field and Pool, or Wildcat Jalmat Yates Gas
15. Elevation (Show whether DF, RT, GR, etc.) 3551' GR	12. County Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

TD 3850', PBD 3651'. Presently completed in Jalmat Gas zone from perfs 3142-3338'. The Eunice Queen zone was TA by setting latching DR plug in 415D pkr @ 3672' & dumping 3 sx cmt on top to PBD 3651'.
10-3/4" OD 32.75# csg set @ 316'. Cmtd w/275 sx. Circ to surface.
7" OD 20# J-55 csg set @ 3849'. Cmtd w/300 sx. TOC @ 2520'.
Propose to leave casing in hole & plug & abandon in the following manner:
1. Rig up, kill well, install BOP.
2. Dump 6 sx Cl C cmt cont'g 4% gel on top of present 11' cmt plug @ 3651' for a total 40' cmt plug on top of pkr @ 3672'.
3. Spot heavy gelled mud between all cmt plugs.
4. Run & set 7" cmt retr on tbg @ 3115'. Displace 50 sx Cl C cmt cont'g 4% gel below retr, pull up & spot 35' Cl C cmt cont'g 4% gel on top of retr.
5. Spot 100' plug Cl C cmt cont'g 4% gel across top of salt @ 1525'.
6. Spot 10 sx Cl C cmt @ surface, install regulation dry hole marker, clean & level location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED [Signature] TITLE Dist. Drlg. Supv. DATE 11/13/75
APPROVED BY [Signature] TITLE DATE
CONDITIONS OF APPROVAL, IF ANY: