

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

NOV 30 10 57 AM '65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

## SUNDRY NOTICES AND REPORTS ON WELLS

DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		7. Unit Agreement Name	
2. Name of Operator <b>Gulf Oil Corporation</b>		8. Firm or Lease Name <b>H. T. Mattern (NCT-E)</b>	
3. Address of Operator <b>Box 670, Hobbs, New Mexico</b>		9. Well No. <b>8</b>	
4. Location of Well 10. Field and Foot, or Wellbore <b>Arrowhead</b>		11. County <b>Lea</b>	
12. Township <b>22-S</b> 13. Range <b>36-E</b> 14. Section <b>12</b> 15. Elevation (Show whether DT, RT, etc.) <b>3452 GL</b>			

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

REPAIRS/REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPER. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	

16. Description of Proposed or Completed Operations (Clearly state pertinent details, and give pertinent dates, including estimated date of starting any proposed work. SEE RULE 1103.)

3750' TD, 3736' PB.

It is proposed to plug and abandon as follows: Pull rods, pump and tubing. Fill open hole 3654' to 3736' with gravel and fill 5' of casing with sand from 3654' to 3649'. Run tubing open ended. Displace hole with mud. Spot 7 sack, 50', cement plug on bottom. Pull tubing to 500'. Spot 100', 14 sacks, cement plug from 500' to 400' over casing leak. Pull tubing to 50' and spot 7 sack plug from 50' to surface. Clean location and install regulation dry hole marker.

I, I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED \_\_\_\_\_ TITLE **Area Petroleum Engineer** DATE **November 30, 1965**

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE \_\_\_\_\_

CONDITIONS OF APPROVAL, IF ANY: