

McDonald State A/C 1 #7

ATTACHMENT I

1. Build road and location.
2. Tap dryhole marker.
3. Install 3000# wellhead & safety anchors.
4. NU BOPS.
5. Drill out cement & CIBP to PBTD 3817'.
6. Run GR-CNL-CCL from approximately 3800' - 2900'.
7. Perforate Seven Rivers/Queen (selectively) after log evaluation.
8. Acidize Seven Rivers/Queen perforations and open hole with 15% NEFE HCl.
9. Swab well.
10. Frac Seven Rivers/Queen with 19,000 gals. crosslinked gel and 53,000# 20/40 Brady Sand.
11. RIH with 2 7/8" production tbg. to approximately 3700'.
12. ND BOPS. NU wellhead.
13. RIH with pump and rods.
14. Place well on test.