(Other)

F THE INTERIOR (Other Instructions of

SUBMIT IN TRIPLACATE.

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

Budget Bureau No. 42 R1424. 5. LEASE DESIGNATION AND SERIAL NO.

GEOLOGICAL SURVEY			IC 030132 (b) 6. IF INDIAN, ALLOTTEE OR TRIBE NAME	
SUNDRY NOTICES AND REPORTS ON WELLS (Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use "APPLICATION FOR PERMIT" for such proposals.)				
1. OIL 6AS			7. UNIT AGREEMENT NAME	
WELL WELL X OTHER			-	
2. NAME OF OPERATOR			8. FARM OR LEASE/NAME	
Cities Service Oil Company			/ Closson-B	
3. ADDRESS OF OPERATOR			9. WELL NO.	
P. O. Box 1919, Midland, Texas 79702			# 6 /	
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements. See also space 17 below.)			10, FIELD AND POOL, OR WILDCAT	
At surface 1980' FNL, 660' FWL of Sec. 20, T-22-S, R-36-E,			Jalmat Yodes Gas	
Lea County, New Mexico			11. SEC., T., R. M., OR BLK. AND SUBJECT OR ABEA	
nea country, nea	V MCATCO		HOLDE OR AREA	
			Sec. 20, T-22	-S, R-36-E
14. PERMIT NO.	15. ELEVATIONS (Show whether DF	15. ELEVATIONS (Show whether DF, RT, GR, etc.)		13. STATE
	3578' GR		Lea	New Mexico
16. Check A	ppropriate Box To Indicate N	lature of Notice, Report, or (Other Data	-
NOTICE OF INTENTION TO:			UENT REPORT OF:	
1 . 1		1	REPAIRING W	
TEST WATER SHUT-OFF	CULL OR ALTER CASING	WATER SHUT-OFF		
FRACTURE TREAT	MULTIPLE COMPLETE	FRACTURE TREATMENT	ALTERING CA	- 1,-
SHOOT OR ACIDIZE	ABANDON*	SHOOTING OR ACIDIZING	ABANDONMEN	\ <u>\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\</u>
REPAIR WELL	CHANGE PLANS	(Other)		

SCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly State all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)* 17 DESCRIBE PROPOSED OR COMPLETED OPERATIONS

This well was plugged and abandoned in the following manner: T.D. 3805'; P.B.T.D. 3493'.

- 1. MIRU casing puller. Pull tubing.
- Set CIBP at 3240'. Circ. hole with 10#/gal. mud. Displaced 5 sacks cement plug (50') on top of CIBP - 3240' to 3190'.
- Shot 5-1/2" casing off at 2010' and pulled 2020' (64 joints).
- Mixed and pumped 50 sacks cement plug 1/2 in and 1/2 out of 5-1/2" casing stub at 2010'. Top of plug at 1880'.
- Mixed and pumped 40 sacks cement plug 1/2 in and 1/2 out of 8-5/8" casing shoe at 1498'. Top of cement plug at 1441'.
- Spotted 10 sacks cement plug from 30' to surface.
- Installed " dry hole marker.

Blackie Coshow with U.S.G.S. witnessed the job.

Region Oper. Manager

(This space for Federal or State office use)

APPROVED BY CONDITIONS OF APPROVAL, IF ANY:

*See Instructions on Reverse Side

ACTING DISTRICT ENGINEER