

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
GEOLOGICAL SURVEY

SUBMIT IN TRIPPLICATE  
(Other instructions on  
reverse side)

Form approved.  
Budget Bureau No. 42-R1424.

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.  
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. <input type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER		5. LEASE DESIGNATION AND SERIAL NO. LC 030132 (b)
2. NAME OF OPERATOR Cities Service Oil Company		6. IF INDIAN, ALLOTTEE OR TRIBE NAME
3. ADDRESS OF OPERATOR P. O. Box 1919, Midland, Texas 79702		7. UNIT AGREEMENT NAME
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements. See also space 17 below.) At surface 1980' FNL, 660' FWL of Section 20, T-22-S, R-36-E, Lea County, New Mexico.		8. FARM OR LEASE NAME Closson-B
14. PERMIT NO.		9. WELL NO. 6
15. ELEVATIONS (Show whether DF, RT, GR, etc.) 3578' GR		10. FIELD AND POOL, OR WILDCAT Jalmat Yates Gas
		11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA Sec. 20, T-22-S, R-36-E
		12. COUNTY OR PARISH Lea
		13. STATE New Mexico

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

TEST WATER SHUT-OFF

PULL OR ALTER CASING

WATER SHUT-OFF

REPAIRING WELL

FRACTURE TREAT

MULTIPLE COMPLETE

FRACTURE TREATMENT

ALTERING CASING

SHOOT OR ACIDIZE

ABANDON\*

SHOOTING OR ACIDIZING

ABANDONMENT\*

REPAIR WELL

CHANGE PLANS

(Other)

(NOTE: Report results of multiple completion on Well  
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting and proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.) \*

T.D. 3805'; PBDT 3493'. We will plug and abandon this well in the following manner:

1. Kill well & install BOP.
2. Load hole with mud-laden fluid and pull tubing.
3. Set CIBP at approximately 3240' and dump 5 sacks of cement on top.
4. Pull approximately 2543' of 5-1/2" casing.
5. Spot 100' (20 sacks) cement plug 1/2 in and 1/2 out of 5-1/2" casing stub.
6. Spot 100' cement (30 sacks) plug 1/2 in and 1/2 out of 8-5/8" casing estimated 1448'-1548'.
7. Spot 50' cement (15 sacks) plug from 50' to surface.
8. Install 4" dry hole marker.

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE Region Operations Manager

DATE 1/19/77

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

APPROVED  
AS AMENDED

JAN 27 1977

ARTHUR R. BROWN  
DISTRICT ENGINEER

\*See Instructions on Reverse Side

RETURNED

FEB 1 1977

OIL CONSERVATION COMM.  
HOBBS, N. M.