

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <u>Inj. Well</u>		7. Unit Agreement Name <u>S. Eunice Unit</u>
2. Name of Operator <u>CONOCO INC.</u>		8. Farm or Lease Name <u>S. Eunice Unit</u>
3. Address of Operator <u>P. O. Box 460, Hobbs, N.M. 88240</u>		9. Well No. <u>18</u>
4. Location of Well UNIT LETTER <u>K</u> <u>1980</u> FEET FROM THE <u>South</u> LINE AND <u>1980</u> FEET FROM THE <u>West</u> LINE, SECTION <u>21</u> TOWNSHIP <u>22S</u> RANGE <u>36E</u> NMPM.		10. Field and Pool, or Wildcat <u>S. Eunice 7 Ryrs Qn.</u>
15. Elevation (Show whether DF, RT, GR, etc.)		12. County <u>Lea</u>

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <u>repair csq. leak</u> <input checked="" type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1703.

MIRU. Rel pkr & POOH. Set RBP @ 3650' & dump 1 sk sand on top. Isolate csq leak w/treating pkr. POOH w/pkr. Set cmt ret @ 50' above leak. Pump 300 sxs class "C" cmt w/2% CaCl₂. Flush w/ 1/2 bbl wtr per 100' tbg in hole. WOC. DO ret & cmt. Press test sqz to 500 psi. Resqz if necessary. Circ sand off RBP & rel. CO to 3811'. Set pkr @ 3648' & place well back on inj.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED [Signature] TITLE Administrative Supervisor DATE 8/21/85

APPROVED BY ORIGINAL SIGNED BY JERRY SEIXON TITLE DISTRICT SUPERVISOR DATE AUG 23 1985
CONDITIONS OF APPROVAL, IF ANY:

RECEIVED

AUG 22 1989

200
HODAS OFFICE