

Submit 3 Copies To Appropriate District Office
District I
1625 N. French Dr., Hobbs, NM 88240
District II
811 South First, Artesia, NM 88210
District III
1000 Rio Brazos Rd., Aztec, NM 87410
District IV
1220 S. St. Francis Dr., Santa Fe, NM 87505

State of New Mexico
Energy, Minerals and Natural Resources

Form C-103
Revised March 26, 1999

OIL CONSERVATION DIVISION
1220 South St. Francis Dr.
Santa Fe, NM 87505

WELL API NO. 30-025-08984
5. Indicate Type of Lease STATE <input type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:
Oil Well ☐ Gas Well ☐ Other INJECTION

2. Name of Operator
BRECK OPERATING CORP.

3. Address of Operator
P.O. BOX 911, BRECKENRIDGE, TEXAS 76424

4. Well Location
Unit Letter G : 1650 feet from the NORTH line and 1650 feet from the EAST line
Section 21 Township 22S Range 36E NMPM LEA County

10. Elevation (Show whether DR, RKB, RT, GR, etc.)
D.F. 3535'

7. Lease Name or Unit Agreement Name:
SOUTH EUNICE UNIT

8. Well No.
12

9. Pool name or Wildcat
EUNICE 7 RIVERS QUEEN, SO

11. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐
PULL OR ALTER CASING ☐ MULTIPLE COMPLETION ☐
OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐
COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐
CASING TEST AND CEMENT JOB ☐
OTHER: ☐

12. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompilation.

Well Bore 8-5/8" casing @ 300'; 5-1/2 casing @ 3832'; Cement top NA; Hole in casing @ 596'-766'; CIBP @ 3460'; No tubing in hole.

1. RIH; Tag CIBP +/- 3460'; Circulate hole with mud
2. Perforate casing @ 3040'
3. Squeeze perforation under packer with 30 sacks of cement; WOC & tag
4. Perforate casing @ 1500'
5. Squeeze perforation under packer with 30 sacks of cement; WOC & tag
6. Perforate casing @ 350'
7. Squeeze perforation under packer with 75 sacks of cement.
8. Cut off wellhead; Spot a 10 sack surface plug; Place dry hole marker

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Linda Venekamp TITLE PRODUCTION CLERK DATE June 28, 2002

Type or print name LINDA VENEKAMP Telephone No. (254) 559-3355

(This space for State use)

APPROVED BY _____ TITLE _____ DATE June 6 2002

Conditions of approval, if any:

ORIGINAL SIGNED BY

PAUL E. KAUTZ

DATE June 6 2002

THE COMMISSION MUST BE NOTIFIED 24 HOURS PRIOR TO THE BEGINNING OF PLUGGING OPERATIONS FOR THE C-103 TO BE APPROVED