

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

OIL CONSERVATION DIVISION
P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.O.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		7. Unit Agreement Name	
2. Name of Operator Apache Corporation		8. Farm or Lease Name Barkeys	
3. Address of Operator 7666 E. 61st Street, Suite 500 Tulsa, Oklahoma 74133-1201		9. Well No. 3	
4. Location of Well UNIT LETTER <u>Y</u> , <u>1650</u> FEET FROM THE <u>North</u> LINE AND <u>2310</u> FEET FROM THE <u>East</u> LINE, SECTION <u>26</u> TOWNSHIP <u>21S</u> RANGE <u>37E</u> N.M.P.M.		10. Field and Pool, or Wildcat Wantz Abo	
15. Elevation (Show whether DF, RT, GR, etc.) 3372.5 GL		12. County Lea	

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103. (Refer to attached wellbore diagram).

- 1) Notify Oil Conservation Division at least 24 hours prior to beginning operations (505) 393-6161.
- 2) RCH w/rods and pump.
- 3) Unseat tag anchor and POH w/tbg.
- 4) RIH wireline. RIH w/cast iron bridge plug and set at 6700'. Dump 35' cmt on top using dump bailer.
- 5) RIH w/tbg open-ended to 6650. Displace hole w/plug mud consisting of 10 #/gal brine and 25 #gel/bbl. POH w/tbg.
- 6) Free pt and cut-off 5 1/2" csg. RIH w/tbg and spot 50 sx Class "C" cmt plug 50' above and below 5 1/2" csg cmt off (should be at approximately 2000'). Pick up 2 stands tbg and WOC.
- 7) RIH w/tbg and tag plug.
- 8) Spot 75 sx Class "C" cmt plug at shoe of 8 5/8" csg w/50' above and below setting depth. Pick up 2 stands and WOC.
- 9) PIH and tag plug.
- 10) Spot 10 sx Class "C" plug w/top 3' below ground level. Out off 8 5/8" sg 3 ft below ground level. Weld on cap at 7' marker w/well name, number and location permanently engraved. Release rig.
- 11) Level and restore location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED [Signature] TITLE Production Engineer DATE March 25, 1988

APPROVED BY DISTRICT 1 SUPERVISOR TITLE DATE MAR 30 1988

CONDITIONS OF APPROVAL, IF ANY:

N 2