

NEW MEXICO OIL CONSERVATION COMMISSION

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. L 1589
7. Unit Agreement Name
8. Farm or Lease Name Ojo Chiso
9. Well No. 1
10. Field and Pool, or Wildcat Ojo Chiso Strawn
12. County Lea

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER <input type="checkbox"/>
2. Name of Operator American Quasar Petroleum Co. of New Mexico
3. Address of Operator 1000 Midland National Bank Tower, Midland, Texas 79701
4. Location of Well UNIT LETTER E, 1980 FEET FROM THE North LINE AND 660 FEET FROM THE West LINE, SECTION 23, TOWNSHIP 22S, RANGE 34E, N.M.P.M.
15. Elevation (Show whether DF, RT, GR, etc.) 3500' DF

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Set CIBP @ 11,500 and cap w/35' cmt (perfs 11,727-890')
2. Cut and pull as much 9 5/8" csg as possible
3. Spot 100' cmt plug in and out of 9 5/8" stub
4. Spot 100' cmt plugs at top of Wolfcamp (11,330'), Abo (11,020'), and Glorietta (8,510'), if not behind pipe
5. Spot 100' cmt plug at 13 3/8" csg shoe (4551')
6. Cut and pull as much 13 3/8" csg as possible
7. Spot 100' cmt plug in and out of 13 3/8" stub
8. Spot 100' cmt plug at top of salt (1700')
9. Spot 100' cmt plug at 20" csg shoe (356')
10. Spot 10 sx surface plug and install marker

NOTE: Work to commence on or around 7/1/77

IT IS HEREBY NOTICED THAT BE NOTICED 24
HOURS BEFORE THE BEGINNING OF
PLUGGING OPERATIONS FOR THE C-103
TO BE APPROVED.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>Gen B. Munnel</u>	TITLE <u>Division Engineer</u>	DATE <u>5/18/77</u>
APPROVED BY <u>Dir. L. Supv.</u>	TITLE <u></u>	DATE <u></u>
CONDITIONS OF APPROVAL, IF ANY:		

RECEIVED

JUL 1 1967

U.S. DEPARTMENT OF COMMERCE
WASHINGTON, D.C.