

Gulf Greer No. 1
Jalmat (Gas) Field
Lea County, New Mexico

Project Engineer: Kevin Midkiff

Office: (915) 688-6828
Residence: (915) 520-4526

Plug and Abandonment Procedure

1. Notify NMOCD 24 hours prior to starting operations. MIRU PU. Kill well if necessary. Monitor for H₂S at all times. ND wellhead, NU BOP. Fish and pull rods. POOH with tubing. Deliver workstring if tubing appears heavily corroded.
2. RIH with casing scraper to $\pm 3250'$, POOH. Set CIBP on tubing at $\pm 3235'$. Circulate hole with 9 ppg gelled brine. Spot a cement plug on the CIBP and across the base of the salt at 2885' - 3235'. Use 25 sxs class C with 2% CaCl₂ added.
3. Pull up to 1590' and spot a plug across the top of the salt at 1470' - 1590'. Use 10 sxs of cement. Pull up to 530' and spot a cement plug to surface. Use 40 sxs of cement. Lay down tubing.
4. Cut off casing 3' below ground level, install P&A marker. Clear, rip, and reseed location.

Approved

J. J. Hemmings

Date:


22 July 92

RPD
[Signature]

MERIDIAN OIL
GULF GREER NO. 1
JALMAT FIELD
LEA COUNTY, NEW MEXICO

KLM 4/27/82


CONDITION AFTER P&A



MERIDIAN OIL
GULF GREER NO. 1
JALMAT FIELD
LEA COUNTY, NEW MEXICO

KLM 4/27/82

CURRENT CONDITION



RECEIVED
JUL 5 1992
AMERICAN OIL & GAS