

PROPOSED WELL PLAN

WELL NAME <u>Burger B-20 No. 2</u>		FIELD <u>NMFU</u>	
<u>ATTACHMENT</u>	<u>NO.</u>	<u>REQUIRED</u>	<u>NOT REQUIRED</u>
CASING CENTRALIZERS, SCRATCHERS	<u> </u>	<u> X </u>	<u> </u>
CEMENTING	<u> </u>	<u> X </u>	<u> </u>
MUD PROGRAM	<u> </u>	<u> X </u>	<u> </u>
WELL PLAN OUTLINE	<u> </u>	<u> X </u>	<u> </u>
PORE PRESSURE - FRAC GRADIENT	<u> </u>	<u> </u>	<u> </u>
PROJECTED PROGRESS	<u> </u>	<u> </u>	<u> </u>
CROSS SECTION OR WELL COURSE	<u> </u>	<u> </u>	<u> </u>
HYDRAULICS PROGRAM	<u> </u>	<u> </u>	<u> </u>
BIT PROGRAM	<u> </u>	<u> </u>	<u> </u>
VENDER USAGE LIST	<u> </u>	<u> </u>	<u> </u>

DRILLING AND COMPLETION PROCEDURE

- (1) 0-1450' Drill 12 1/4" hole. Set and cement 9 5/8" surface casing. WOC 18 hours. Pressure test to 1000 psi for 30 minutes. Drill out.
- (2) 1450'-6760' Drill 8 3/4" hole. Pressure test shoe to 300#. Drill to TD (6760'). Run OH logs. Set and cement 7" production casing. WOC 18 hours. Pressure test to 1000 psi for 30 minutes.
- (3) Detailed completion procedure to be determined from OH log analysis. Anticipate acidizing & sandfracing Blinbry & Tubb Zone.