

PROPOSED WELL PLAN

WELL NAME	SEMU EUMONT NO. 118		FIELD	NMFU
<u>ATTACHMENT</u>	<u>NO.</u>	<u>REQUIRED</u>	<u>NOT REQUIRED</u>	
CASING CENTRALIZERS, SCRATCHERS	_____	X	_____	_____
CEMENTING	_____	X	_____	_____
MUD PROGRAM	_____	X	_____	_____
WELL PLAN OUTLINE	_____	X	_____	_____
PORE PRESSURE - FRAC GRADIENT	_____	_____	_____	_____
PROJECTED PROGRESS	_____	_____	_____	_____
CROSS SECTION OR WELL COURSE	_____	_____	_____	_____
HYDRAULICS PROGRAM	_____	_____	_____	_____
BIT PROGRAM	_____	_____	_____	_____
VENDER USAGE LIST	_____	_____	_____	_____

DRILLING AND COMPLETION PROCEDURE

1. 0'-1300'- Drill a 12-1/4" hole. Run and cement casing. (See cement and casing programs) WOC 18 hours, pressure test casing to 600 psi and drill out.
2. 1300'-3770' - Drill a 7-7/8" hole. Drill out shoe and test formation to 200 psi. Run and cement casing. (See cement and casing programs)
3. Detailed completion procedure to be prepared after open hole logs are analyzed.

NOTE: Casing pressure tests should be 30 minutes in duration.