

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

OIL CONSERVATION DIVISION
P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-79

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. L-4097	

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		7. Unit Agreement Name
2. Name of Operator Yates Petroleum Corporation		8. Farm or Lease Name Pronghorn Unit
3. Address of Operator 105 South 4th St., Artesia, NM 88210		9. Well No. 2
4. Location of Well UNIT LETTER <u>H</u> <u>1980</u> FEET FROM THE <u>North</u> LINE AND <u>660</u> FEET FROM THE <u>East</u> LINE, SECTION <u>30</u> TOWNSHIP <u>22S</u> RANGE <u>33E</u> NMPM.		10. Field and Pool, or Wildcat Wildcat
15. Elevation (Show whether DF, RT, GR, etc.) 3674' GR		12. County Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>
PLUG AND ABANDON <input checked="" type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
OTHER <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1503.

Propose to plug and abandon well as follows:

- 1) Spot plug thru tubing from 4987-4887' across 10-3/4" intermediate casing shoe at 4737'. Tag plug.
- 2) Load 10-3/4" casing w/10 lb/gal salt gel.
- 3) Perforate 2 holes @1000' and 2 holes @950'. Establish circulation down 10-3/4" thru these perforations.
- 4) Cement perforations w/300 sx Class "C". Underdisplace, leaving 50 sx cement inside casing.
- 5) Set 15 sx cement plug at surface and install dry hole marker.

Verbal approval to plug well was given by Mr. Eddie Seay, NMOC, Hobbs, 9-19-86.
NOTIFY NMOC, Hobbs, 24 hours in advance of plugging operations.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Jeroy Sexton TITLE Production Supervisor DATE 9-22-86

ORIGINAL SIGNED BY JEROY SEXTON

APPROVED BY DISTRICT 1 SUPERVISOR TITLE DATE SEP 24 1986

CONDITIONS OF APPROVAL, IF ANY: