

DISTRICT I  
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II  
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III  
1000 Rio Brazos Rd., Aztec, NM 87410

**OIL CONSERVATION DIVISION**  
P.O. Box 2088  
Santa Fe, New Mexico 87504-2088

WELL API NO. 30-025-30793
5. Indicate Type of Lease STATE <input type="checkbox"/> FEE <input checked="" type="checkbox"/>
6. State Oil & Gas Lease No. New
7. Lease Name or Unit Agreement Name Kyte
8. Well No. 1
9. Pool name or Wildcat Warren Tubb - Blinebry

<b>SUNDRY NOTICES AND REPORTS ON WELLS</b> (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)	
1. Type of Well: OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER	
2. Name of Operator Stevens & Tull, Inc.	
3. Address of Operator P. O. Box 11005, Midland, Texas 79702	
4. Well Location Unit Letter J : 1980 Feet From The East Line and 1980 Feet From The South Line Section 23 Township 20-S Range 38-E NMPM Lea County	
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 3566.5' GR	

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
<b>NOTICE OF INTENTION TO:</b>	<b>SUBSEQUENT REPORT OF:</b>
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
PLUG AND ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
OTHER: <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>
	OTHER: Completion Operations <input checked="" type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- 1) Perforate 1 Jet Shot Per Location at 6838-7003 (43 holes)
- 2) Acidize 6838 - 7003 with 3000 gallons 20% NE-FE
- 3) Swab test. Recover water.
- 4) Set Cast Iron Bridge Plug at 6832' with 2 sacks cement.
- 5) Perforate 1 Jet Shot Per Location at 6586 - 6797 (41 holes)
- 6) Acidize 6586 - 6797 with 3000 gallons 15% NE-FE. Recover 10% oil.
- 7) Frac 6586 - 6797 with 42,000 gallons 2% KCL at 33 BPM with 165,000# 20/40 sand. Recover 10% oil.
- 8) Set Cast Iron Bridge Plug at 6570'.
- 9) Perforate 1 Jet Shot Per Location over 5909 - 6330 (85 holes)
- 10) Acidize 5909 - 6330 with 4300 gallons 15% NE-FE. Recover 25% oil.
- 11) Frac 5909 - 6330 with 71,000 gallons 2% KCL at 40 Barrels per minute with 290,000# 20/40 sand.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Rodney L. Seale TITLE Engineer DATE 8/9/90  
TYPE OR PRINT NAME Rodney L. Seale TELEPHONE NO. 915/699-1410

(This space for State Use)

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE \_\_\_\_\_

CONDITIONS OF APPROVAL, IF ANY: