

MARALO, INC.
WILD TURKEY "9" STATE, #1
LIVINGSTON RIDGE; DELAWARE E.
LEA, NM

17. Release pkr. Drop down and catch RBP. PU and set RBP @ +/- 7100' and pkr @ +/- 6900' isolating Zone 5.
18. Frac Zone 5 w/9500 gals Spectra-frac G-3000 + 14,500# 20/40 Ottawa sand + 6,000# 20/40 resin coated sand down tbg at a rate of +/- 8 BPM. Pump as in Step 16.
19. Release pkr. Drop down and catch RBP. Drop down and set RBP @ +/- 8850'. PU and set pkr @ +/- 6900'.
20. Swab and evaluate Zones 2 - 5. If well will flow, leave flowing until it dies.
21. Release pkr. Drop down and catch RBP. TOH w/tbg, pkr & RBP. If determined in Step 10, set CIBP over Zone 1 at this time.
22. TIH w/pumping equipment and place well on production.