

Submit 3 Copies To Appropriate District Office
District I
1625 N. French Dr., Hobbs, NM 88240
District II
1301 W. Grand Ave., Artesia, NM 88210
District III
1000 Rio Brazos Rd., Aztec, NM 87410
District IV
1220 S. St. Francis Dr., Santa Fe, NM 87505

State of New Mexico
Energy, Minerals and Natural Resources

OIL CONSERVATION DIVISION
1220 South St. Francis Dr.
Santa Fe, NM 87505

Form C-103
Revised March 25, 1999

WELL API NO. 30-025-03540	
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>	
6. State Oil & Gas Lease No.	
7. Lease Name or Unit Agreement Name: State "A"	
8. Well No. #2	
9. Pool name or Wildcat Jalmat; Tan-Y-7R	
SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)	
1. Type of Well: Oil Well <input checked="" type="checkbox"/> Gas Well <input type="checkbox"/> Other <input type="checkbox"/>	
2. Name of Operator Pro Gas Operating, Inc.	
3. Address of Operator P.O. Box 60243, Midland, Texas 79711	
4. Well Location Unit Letter J0 660 feet from the South line and 1,980 feet from the East line Section 36 Township 21-S Range 35-E NMPM County Lea	
10. Elevation (Show whether DR, RKB, RT, GR, etc.)	

11. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

- PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐
PULL OR ALTER CASING ☐ MULTIPLE COMPLETION ☐
OTHER: ☐

SUBSEQUENT REPORT OF:

- REMEDIAL WORK ☐ ALTERING CASING ☐
COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐
CASING TEST AND CEMENT JOB ☐
OTHER: ☐

12. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompilation.

9-5/8" @ 305' w/ 150 sx
5-1/2" @ 3,999' w/ 350 sx TOC 2,000' calc.

Perforations: 3,820 - 3,830'

THE COMMISSION MUST BE NOTIFIED 24 HOURS PRIOR TO THE BEGINNING OF PLUGGING OPERATIONS FOR THE C-103 TO BE APPLIED.

1. Dig & line earthen work pit, flow well down as needed. MIRU. POOH laying down rods and pump. NU BOP and POOH w/ production tbq.
2. RIH w/ gauge ring to 3,750'. RIH w/ tbq-set CIBP to 3,750' and set CIBP. Load hole w/ mud and pump 25 sx C cmt on CIBP.
3. Cut and pull 5 1/2" casing from 1,700'.
4. RIH w/ tbq to 1,750' and pump 50 sx C cmt w/ 2% CaCl₂ @ 1,750'. WOC and tag this plug. **Csg stab & base salt plug**
5. RIH w/ tbq to 355' and pump 60 sx C cmt w/ 2% CaCl₂ 355 - 255'. WOC & tag. **Surface sg shoe plug**
6. Pump 10 sx C cmt 50' to surface. **surface plug**
7. Cut off wellhead and install dryhole marker. Cut off anchors and level location

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE  TITLE Engineer DATE 07/15/02

Type or print name James F. Newman, P.E. Triple N Services, Inc. Telephone No. 915-687-1994
(This space for State use)

APPROVED BY PAUL F. KAUTZ TITLE PETROLEUM ENGINEER DATE JUL 18 2002
Conditions of approval, if any: