

Submit 3 Copies To Appropriate District Office
District I
1625 N. French Dr., Hobbs, NM 88240
District II
1301 W. Grand Ave., Artesia, NM 88210
District III
1000 Rio Brazos Rd., Aztec, NM 87410
District IV
1220 S. St. Francis Dr., Santa Fe, NM 87505

State of New Mexico
Energy, Minerals and Natural Resources

OIL CONSERVATION DIVISION
1220 South St. Francis Dr.
Santa Fe, NM 87505

WELL API NO.

30-025-03542

5. Indicate Type of Lease

STATE ☒ FEE ☐

6. State Oil & Gas Lease No.

7. Lease Name or Unit Agreement Name:

State "A"

8. Well No. #1

9. Pool name or Wildcat

Jalmar, Tan-Y-712

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:

Oil Well ☒ Gas Well ☐ Other ☐

2. Name of Operator Pro Gas Operating, Inc.

3. Address of Operator

P.O. Box 60243, Midland, Texas 79711

4. Well Location

Unit Letter J : 2,310 feet from the South line and 1,650 feet from the East line

Section 36 Township 21-S Range 35-E NMPM County Lea

10. Elevation (Show whether DR, RKB, RT, GR, etc.)
3,623' DF

11. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒

TEMPORARILY ABANDON ☐ CHANGE PLANS ☐

PULL OR ALTER CASING ☐ MULTIPLE COMPLETION ☐

OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐

COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐

CASING TEST AND CEMENT JOB ☐

OTHER: ☐

12. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

8-5/8" @ 323' w/ 150 sx

5-1/2" @ 3,885' w/ 450 sx TOC 1,200' calc.

Perforations: 3,800 -- 3,848'

1. Dig & line earthen work pit, flow well down as needed. MIRU. POOH laying down rods and pump. NU BOP and POOH w/ production tbg.
2. RIH w/ gauge ring to 3,750'. RIH w/ tbg-set CIBP to 3,750' and set CIBP. Load hole w/ mud and pump 25 sx C cmt on CIBP.
3. POOH w/ tbg to 1,750' and pump 25 sx C cmt @ 1,750'. **TOP Base of Salt plug**
4. RIH w/ wireline and perforate 5 1/2" casing @ 373'.
5. RIH w/ packer to 200' and squeeze 50 sx C cmt 373 - 273'. WOC & tag. **Surface sg shoe plug**
6. Pump 10 sx C cmt 50' to surface. **surface plug**
7. Cut off wellhead and install dryhole marker. Cut off anchors and level location.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE: James F. Newman TITLE: Engineer DATE: 07/15/02

Type or print name: James F. Newman, P.E. Triple N Services, Inc. Telephone No. 915-687-1994
(This space for State use)

APPROVED BY: PAUL F. KAUTZ TITLE: PETROLEUM ENGINEER DATE: JUL 18 2002
Conditions of approval, if any: