

OIL CONSERVATION DIVISION
P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
V-37	

<p align="center">SUNDRY NOTICES AND REPORTS ON WELLS</p> <p align="center"><small>(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)</small></p>		
<p>1. <input checked="" type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER-</p>		7. Unit Agreement Name
2. Name of Operator John Yuronka		8. Farm or Lease Name Charm State
3. Address of Operator 807 Petroleum Bldg., Midland, TX 79701		9. Well No. #1
<p>4. Location of Well</p> <p>UNIT LETTER <u>P</u> <u>660</u> FEET FROM THE <u>South</u> LINE AND <u>990</u> FEET FROM</p> <p>THE <u>East</u> LINE, SECTION <u>36</u> TOWNSHIP <u>21-S</u> RANGE <u>35-E</u> NMPM.</p>		10. Field and Pool, or Wildcat Jalmat
<p>15. Elevation (Show whether DF, RT, GR, etc.)</p> <p align="center">3602' DF</p>		12. County Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data			
NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Procedure to Plug and Abandon:

1. Pull rods, pump and tubing.
2. Rerun tubing w/cement retainer and set @ approximately 3650'.
3. Squeeze perforations 3760'-3874' w/200 sacks cement and set 35' of cement on top of retainer.
4. Perforate @ approximately 1940' @ base of Anhydrite and attempt to circulate. If able to circulate, cement to surface. If unable to circulate, place 100' cement plug in 5-1/2".
5. 10 Sack cement plug at surface w/marker.
- 9.5# Brine water w/25 sacks salt gel per 100 bbls. will be inserted between plugs.

**If unable to circulate, must reperforate at base of surface casing and squeeze.
If able to circulate, need a 100' plug at * 5/8" shoe
10 sx at surface

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>John Yuronka</u>	TITLE <u>Authorized Agent</u>	DATE <u>July 2, 1984</u>
APPROVED BY <u>Edwin W. Dean</u>	TITLE <u>OIL & GAS INSPECTOR</u>	DATE <u>JUL - 2 1984</u>
CONDITIONS OF APPROVAL, IF ANY:		

SEE ABOVE