

## Evans State #3

### P&A Procedure

Page 2

14. Pour estimated 140 cu ft ZONITE to set plug across top of salt & extend 50' above shoe = 1145 - 1380'. Vol based on 11" OH. Set plug in stages, checking w/ SL to assure bridges are not occurring and required plug height is achieved. Pour at rate that minimizes potential to bridge. After setting plug, add water as necessary to assure hydration of plug.
15. Insert & push 85/8" wiper plug to 30' w/ SL. Fill csg w/ ZONITE to 3' from surface (9 cu ft). Add water as needed to hydrate plug.
16. Secure wellbore and RD equip.
17. Allow 48 hours for ZONITE to hydrate, remove WH, cut off casings 3' below GL and cap wellbore.
18. Install dry hole marker stamped w/ required well identification, 4" OD x 4' above GL.
19. Remove all equip and cut deadmen below GL.
20. Turn over to Chevron for any surface remediation work.

**Estimated ZONITE Requirements:**

**163 ft<sup>3</sup>**