

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

# NEW MEXICO OIL CONSERVATION COMMISSION

3 - OCC  
1 - File

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

## SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER <input type="checkbox"/>		7. Unit Agreement Name
2. Name of Operator <b>Tidewater Oil Company</b>		8. Farm or Lease Name <b>R. M. Marshall</b>
3. Address of Operator <b>Box 249, Hobbs, New Mexico</b>		9. Well No. <b>2</b>
4. Location of Well UNIT LETTER <b>H</b> <b>660</b> FEET FROM THE <b>South</b> LINE AND <b>660</b> FEET FROM THE <b>East</b> LINE, SECTION <b>13</b> TOWNSHIP <b>21 S</b> RANGE <b>36 E</b> N.M.P.M.		10. Field and Pool, or Wildcat <b>Eumet</b>
15. Elevation (Show whether DE, RT, GR, etc.) <b>3525 Gr.</b>		11. County <b>Lea</b>

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐  
TEMPORARILY ABANDON ☐  
PULL OR ALTER CASING ☐  
OTHER ☐

PLUG AND ABANDON ☒  
CHANGE PLANS ☐  
OTHER ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐  
COMMENCE DRILLING OPNS. ☐  
CASING TEST AND CEMENT JOBS ☐  
OTHER ☐  
ALTERING CASING ☐  
PLUG AND ABANDONMENT ☐

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

It is proposed to plug and abandon this well as follows: Lay 25 sack cement plug across top of Queen formation at 3474', Lay 25 sack cement plug across top of Seven Rivers formation at 2971', Lay 25 sack cement plug across bottom of 8-5/8" casing at 2804'. Cut off 8-5/8" casing at deepest free point and pull. Lay 25 sack cement plug across top of 8-5/8" casing. If casing is pulled from below salt section, will isolate same with 25 sack cement plugs at top and bottom. Lay 25 sack cement plug across 13-3/8" surface casing shoe at 294' and lay 10 sack cement plug at surface. Install dry hole marker. Mud laden fluid will be left between all plugs.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED C. E. Wade TITLE Area Supt. DATE 8-29-66  
APPROVED BY [Signature] TITLE \_\_\_\_\_ DATE \_\_\_\_\_  
CONDITIONS OF APPROVAL, IF ANY: