

OIL CONSERVATION DIVISION  
P. O. BOX 2088  
SANTA FE, NEW MEXICO 87501

Form C-103  
Revised 10-1-78

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease  
State  Fee

5. State Oil & Gas Lease No.  
**A2742**

SUNDRY NOTICES AND REPORTS ON WELLS  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL  GAS WELL  OTHER

2. Name of Operator  
**TEXACO PRODUCING INC**

3. Address of Operator  
**P.O. BOX 728, HOBBS, NEW MEXICO 88240**

4. Location of Well  
UNIT LETTER **A** **330** FEET FROM THE **NORTH** LINE AND **330** FEET FROM THE **EAST** LINE, SECTION **19** TOWNSHIP **21-S** RANGE **36-E** NMPM.

7. Unit Agreement Name

8. Farm or Lease Name  
**STATE AV**

9. Well No.  
**1**

10. Field and Pool, or Wildcat  
**EUNICE MONUMENT GRAYBURG SAN ANDRES**

12. County  
**LEA**

15. Elevation (Show whether DF, RT, GR, etc.)  
**3624' G.R.**

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1703.

- MIRU. POH WITH 3 1/2" TUBING, O.D.I PUMP PROTECTOR AND PUMP.
- TIH W/ 6 1/4" BIT. CLEANOUT WELL TO 3824' (7" CSG SHOE) - CIRC HOLE FULL OF 9.5 LB PER GAL MUD.
- TOH.
- GIH AND SET CEMENT RETAINER AT 3804'. SQUEEZE 100 SX CLASS CEMENT WITH 2% CaCl<sub>2</sub> INTO OPEN HOLE 3824'-4000'. PULL UP AND SPOT 6 SX CEMENT (35' PLUG) ON TOP OF RETAINER.
- TOH.
- RUN FREE POINT ON 7" CASING. CUT-OFF 7" CSG (APPROX. AT 2954', GOOD CEMENT UPTO 3000'). POH WITH 7" CASING.
- GIH AND SPOT 50 SX (100' PLUG) ACROSS 9 5/8" CSG SHOE 2884'-2984'.
- POH AND SPOT 35 SX (100' PLUG) ACROSS TOP OF SALT (1430')/1330'-1430'.
- TOH.
- PERFORATE 9 5/8" CSG AT 378'. ESTABLISH CIRCULATION AND PUMP 100 SX CEMENT, CIRC LEMENT THRU 9 5/8" - 12 1/2" ANNULUS. ALSO PUMP 125 SX CEMENT TO FILL 9 5/8" CSG FROM 378' TO SURFACE.
- CUT OFF WELL HEAD AND INSTALL DRY HOLE MARKER.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED *Paul Kautz* TITLE AREA SUPERINTENDENT DATE OCT 10 1988

Orig. Signed by Paul Kautz Geologist. DATE OCT 12 1988

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE \_\_\_\_\_

CONDITIONS OF APPROVAL, IF ANY