

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

## SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <input type="checkbox"/>		5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
2. Name of Operator <b>Chevron Oil Company</b>		5. State Oil & Gas Lease No. <b>B-1846-1</b>
3. Address of Operator <b>P. O. Box 1660, Midland, Texas 79701</b>		7. Unit Agreement Name
4. Location of Well UNIT LETTER <b>Q</b> , <b>1980</b> FEET FROM THE <b>East</b> LINE AND <b>660</b> FEET FROM THE <b>South</b> LINE, SECTION <b>20</b> TOWNSHIP <b>21S</b> RANGE <b>36E</b> NMPM.		8. Farm or Lease Name <b>State 2-20</b>
		9. Well No. <b>1</b>
		10. Field and Pool, or Wildcat <b>Kumont</b>
15. Elevation (Show whether DF, RT, GR, etc.) <b>3637 DF</b>		12. County <b>Leon</b>

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

**Estimated date of starting proposed work is March 15, 1973**

1. Dig work pit and clean cellar. Install ROPE.
2. Run tubing to 23900' and spot 40 sack cement plug from 23900' to 23600'.
3. Spot 25 sack cement plug at 1700'.
4. Perforate 7" casing at 2100'. Pump sufficient cement to fill 7" x 8-5/8 annulus to surface leaving 7" full of cement to surface.
5. Cut casings 3' below ground level, weld steel plate and install proper hole marker extending 4' above ground level. Fill pit and clean up location.

*24 hr. notice*

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED J. E. Fullis Division Dir. Supt. DATE March 2, 1973

APPROVED BY Joe D. Emery TITLE Dist. Dir. DATE   
CONDITIONS OF APPROVAL, IF ANY: