

*Summarized Restoration Procedure:*

EMSU #439 was shut-in after having a hole in the tubing. This restoration was designed to reactivate the well from its shut-in status by re-running the tubing, pump, and rods into the existing wellbore for further production.

- 1) MIRU pulling unit. NU BOP.
- 2) RIH with production tubing.
- 3) Test tubing to 500#. ND BOP.
- 4) RIH with new pump and rods.
- 5) Space out and clamp off.
- 6) Hang well on and RD pulling unit.
- 7) Test pump and put back on production.
- 8) Notify field office personnel of well status.