

Eunice Monument South Unit # 443  
API: 30-025-04743  
S21, T21S, R36E, Unit Letter G  
August 28, 2001

WBS # UWPWB-A1  
1980' FNL & 1980' FEL  
Lea County, NM

**Recommended Plug & Abandon Procedure**  
**Notify OCD 24 hrs prior to operations.**

1. MIRU PU. Conduct Safety Meeting. ND WH. NU BOP.  
Verify dead man anchors have been set and tested.
2. RIH w/WS, RU Sierra.
3. RU cmt. Cap existing CIBP set @ 3709', w/25 sxs Class 'C' cement from 3709'-3609' (100' cmt plug). The top of the Unitized Interval is at 3709'. Tag cement.
4. Spot 100' Class 'C' cmt plug from 3574' to 3474', @ the top of the Queen formation.
5. Spot 100' cmt plug, from 2770' to 2670' @ the base of Salt.
5. Spot 100' cmt plug, from 1548' to 1448', @ 7-5/8" casing shoe and Top of Salt..
6. Spot 10 sxs CI 'C' cmt plug from 60' to Surface.
7. RD CMT. WOC. ND BOP. RD PU.
8. ND wellhead. Cut off casing 4' below GG & cap.
9. Install 4" marker 4' above GL w/the following stamped on it:

Chevron U.S.A. Inc.  
EMSU # 443  
1980' FNL & 1980' FEL  
T21S, R-36E, Sec. 21, UL G  
Lea County, NM

10. Remove all equip, deadman, and junk from location.
10. Fill any pits and level location.

Class C Cement:  
1% CaCl (Cement Accelerator)  
0.5 BA-10 (Fluid Loss Additive)  
0.3 CD-32 (Cement Dispersant)  
Pkr Fl : 10# Brine mud w/25# of gel per BBL

Joseph Payne  
Petroleum Engineer  
CTN 687-7105

Casing	Depth
Surf Csg	16" @ 29'
Interm Csg	7-5/8" @ 1498'
Prod Csg	5-1/2" @ 3795'

  

Formation Tops	Depth
T/Salt	1503'
B/Salt	2770'
T/Queen	3574'
T/Penrose	3710'
T/Grayburg	3868'
T/Grayburg/2	3907'
T/Grayburg/2A	3944'
T/Grayburg/3	3977'
T/Grayburg/4	4021'
T/Grayburg/5	4081'
T/San Andres	4135'