

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. <b>B-1481</b>	
7. Unit Agreement Name	
8. Farm or Lease Name <b>State M</b>	
9. Well No. <b>2</b>	
10. Field and Pool, or Wildcat <b>Arrowhead-Grayburg</b>	
12. County <b>Lea</b>	

**SUNDRY NOTICES AND REPORTS ON WELLS**  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>
2. Name of Operator <b>Cities Service Oil Company</b>
3. Address of Operator <b>Box 69, Hobbs, New Mexico 88240</b>
4. Location of Well UNIT LETTER <b>L</b> , <b>1980</b> FEET FROM THE <b>South</b> LINE AND <b>660</b> FEET FROM THE <b>West</b> LINE, SECTION <b>36</b> TOWNSHIP <b>21</b> RANGE <b>36</b> N.M.P.M.
15. Elevation (Show whether DF, RT, GR, etc.) <b>3555 GR</b>

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>
OTHER <input type="checkbox"/>	OTHER <input type="checkbox"/>
PLUG AND ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

We propose to perform remedial work on the above well as follows: Squeeze perforations (3805-31, 4 holes/ft.) with 50 sacks Class "C" cement with 0.3% Hallad 9 followed by 50 sacks Class "C" w/3 pounds salt and 5 pounds sand per sack. Drill out cement to top of liner, drill out cement to 3825' w/Klustrite shoe.

Perforate from 3808' to 3812' and 3790' to 3800' w/2 shots/ft. Acidize perforations with 1400 gallons clean up acid.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED \_\_\_\_\_ TITLE **District Admin. Supervisor** DATE **11-17-69**

APPROVED BY *Leslie A. Clements* TITLE \_\_\_\_\_ DATE **NOV 17 1969**

CONDITIONS OF APPROVAL, IF ANY: