

DISTRICT I
1625 N. French Dr., Hobbs, NM 88240

DISTRICT II
811 South First, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

DISTRICT IV
2040 South Pacheco, Santa Fe, NM 87505

OIL CONSERVATION DIVISION
2040 South Pacheco
Santa Fe, NM 87505

WELL APINO.	
30-025-06514	
5. Indicate Type of Lease <input type="checkbox"/> STATE <input checked="" type="checkbox"/> FEE	
6. State Oil & Gas Lease No.	
7. Lease Name or Unit Agreement Name Livingston	
8. Well No.	3
9. Pool name or Wildcat Hare; San Andres, East	
4. Well Location Unit Letter <u>W</u> : <u>560</u> Feet From The <u>South</u> Line and <u>2030</u> Feet From The <u>East</u> Line Section <u>3</u> Township <u>21S</u> Range <u>37E</u> NMPM <u>Lea</u> County 10. Elevation (Show whether DF, RT, GR, etc.) <u>3421'</u> <u>GR</u>	

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:
☒ OIL WELL ☐ GAS WELL ☐ OTHER

2. Name of Operator

Apache Corporation

3. Address of Operator

2000 Post Oak Blvd., Ste. 100, Houston, Texas 77056-4400

4. Well Location

Unit Letter W : 560 Feet From The South Line and 2030 Feet From The East Line
Section 3 Township 21S Range 37E NMPM Lea County

10. Elevation (Show whether DF, RT, GR, etc.)
3421' GR

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

- ☐ Perform Remedial Work ☐ Plug and Abandon
☐ Temporarily Abandon ☐ Change Plans
☐ Pull or Alter Casing
☐ Other

SUBSEQUENT REPORT OF:

- ☐ Remedial Work ☐ Altering Casing
☐ Commence Drilling Operations ☐ Plug and Abandonment
☐ Casing Test and Cement Job
☒ Other Plugback

12. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

- 9/11/00 MIRU. Pull out of hole w/ production equipment.
- 9/12/00 Run in hole w/ CIBP, set @ 7100' & dump cement on top. Pull out of hole. Pick up & run in hole w/ CIBP, set @ 5550' & dump cement on top. Pull out of hole.
- 9/13/00 Test casing to 1000#. Perforate casing w/ 4 holes @ 4015'. Obtain circulation.
- 9/14/00 Cement squeeze behind 5-1/2" casing w/ 590 sx cement. Circulate 80 sx to pit.
- 9/18/00 Run in hole w/ 4-3/4" bit. Tag cement @ 3865'. Drill out cement to 4015'. Circulate hole clean. Pull out of hole w/ bit. Pressure test casing to 3500#.
- 9/19/00 Perforate San Andres @ 3853' - 3858', 3864' - 3870', 3886' - 3908', 3921' - 3925', 3932' - 3962'.
- 9/20/00 Acidize San Andres w/ 3000 gals 15% HCL.
- 9/21/00 Frac San Andres w/ 24400 gals gel & 40000# 12/20 sand. Tag sand @ 3875'. Clean out sand to PBTD @ 4015'.
- 9/25/00 Run in hole w/ production equipment & set @ 3975'. Set pumping unit. Return to production.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE

Debra J. Anderson

TITLE Sr. Engineering Technician

DATE 10/24/00

TYPE OR PRINT NAME

Debra J. Anderson

TELEPHONE NO. 713-296-6338

(This space for State Use)

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

NOV 28 2000

2A Wanta Abo