State of New Mexico

, пиодии	ر	Cobies	to Appronate	Distric
Office				

DISTRICT I 1625 N. French Dr., Hobbs, NM 88240 DISTRICT II 811 South First, Artesia, NM 88210	OIL CONSERVATION 1220 South St. France	DIVISION	FORM C-103 Revised March 25, 1999 WELL API NO.				
<u>DISTRICT II</u>		DIVISION					
		DIVISION	WELL ADINO				
811 South First, Artesia, NM 88210	1220 South St. Franc	OIL CONSERVATION DIVISION					
		30-025-06590					
DISTRICT III	Santa Fe, NM 87	/505	5. Indicate Type of Lease				
1000 Rio Brazos Rd., Aztec, NM 87410 DISTRICT IV			STATE FEE 6. State Oil & Gas Lease No.				
1220 South St. Francis Dr., Santa Fe, NM 875	ns		o. State Off & GAS Lease No.				
	Y NOTICES AND REPORTS ON WELL	I O					
i	PROPOSALS TO DRILL OR TO DEEPEN OR PI	7. Lease Name or Unit Agreement Name					
	"APPLICATION FOR PERMIT" (FORM C-101) F						
PROPOSALS.)		Northeast Drinkard Unit					
1. Type of Well:			1				
OIL WELL	☐ GAS WELL ☐ OTHER						
2. Name of Operator			8. Well No.				
Apache Corporation		608					
3. Address of Operator	100 IV T TT056 4400		9. Pool name or Wildcat				
2000 Post Oak Blvd., Ste. 14. Well Location	100, Houston, Texas 77056-4400		Eunice N., Blinebry-Tubb-Drinkard				
Unit Letter F	: 1980 Feet From The North	Line and 1880	Feet From The West Line				
1.5	210	·					
Section 15	Township 21S Range 3/		A Lea County				
	3441' GR	, , . ,					
11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data							
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:							
pang .	—	Down of all Mark	-				
Perform Remedial Work	☐ Plug and Abandon	Remedial Work	☐ Altering Casing				
Temporarily Abandon	Change Plans	Commence Dril	lling Operations				
Pull or Alter Casing	-	Casing Test and	d Coment Joh				
			d Cement 300				
Other		Other					
12. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.							
MIRU Fleet Cementers. Circulate well w/ 95.# mud. Run in hole w/ 4" casing gun. Tag cement on top of CIBP @ 5476'. Pull up hole to 2855' and perforate. Run in hole to 2855' and pump 25 sx cement. Wait on cement and tag @ 2798'. Pull up hole to 1300'. Spot 25 sx cement plug. Wait on cement and tag @ 1055'. Run in hole w/ 4" casing gun and perforate @ 365'. Run in hole to 385'. Break circulation. Circulate 300 sx cement to surface inside and outside casing. Install P&A marker. Clean location.							
			2 45 16 17 73 70 30 30 30 30 30 30 30 30 30 30 30 30 30				
Thereby certify that the information above is true and complete to the best of my knowledge and relief. SIGNATURE TITLE Sr. Engineering Technician DATE 11/5/2001 THE PRINT NAME TO THE PRINT							

APPROVED BY Johnson Ruhman Conditions of APPROVAL, IF ANY: GWW

TITLE COMPLIANCE OFFICER

FEB 2 5 2003