

1. MIRU PU. LD rods and pump. ND wellhead and NU BOP. POOH w/252 jts 2 3/8" tbg. NU 7 1/16" 3M frac valve. RU Wireline lubr. Ran GR/CCL from 7710' to 7400'. Ran and set 5 1/2" CIBP at 7680'. Perf McKee w/4" csg guns, 1 JSPF from 7432-66', 7480', 7481', 7561', 7571', 7577', 7579', 7590'-7616'. Total 68 shots.
2. RD Wireline, ND frac valve.
3. TIH w/5 1/2" RTTS pkr on 238 jts, 2 3/8" tbg to 7365'.
4. RU Halliburton, acidize McKee perms w/2500 gals 7 1/2% NEFE, w/105 1.3 SG ball sealers for divert.
5. Swab well.
6. Release RTTS pkr at 7365' and POOH with pkr.
7. TIH w/mud anchor, perf sub, SN, 10 jts 2 3/8" tbg, TAC, 236 jts 2 3/8" tbg to 7650'. ND BOP. RIH w/rods and pump. Hang well on and start pumping.