

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS <small>(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE APPLICATION FOR PERMIT - " (FORM C-101) FOR SUCH PROPOSALS.)</small>		
1. <input type="checkbox"/> OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER-		7. Unit Agreement Name
2. Name of Operator Brunson & McKnight		8. Farm or Lease Name Berry
3. Address of Operator P. O. Box 1039, Hobbs, New Mexico 88240		9. Well No. 1
4. Location of Well UNIT LETTER <u>N</u> <u>554</u> FEET FROM THE <u>South</u> LINE AND <u>1821</u> FEET FROM THE <u>West</u> LINE, SECTION <u>7</u> TOWNSHIP <u>21S</u> RANGE <u>34E</u> NMPM.		10. Field and Pool, or Wildcat Berry - Morrow
15. Elevation (Show whether DF, RT, GR, etc.) 3750 GR		12. County Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data			
NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Killed well.
2. Removed head and put on Blowout Preventer.
3. Unseated packer and pulled tubing.
4. Set bridge plug in 4 1/2" casing @ 13,005', capped with 35' of cement.
5. Displaced hole with salt- gel mud.
6. Cut and pulled 4998' of 4 1/2" casing.
7. Set 100' plug across stub @4998'.
8. Set 100' plug in 9 5/8 from 1950-1850'.
9. Set 100' plug in 9 5/8 from 475-375'.
10. Set surface plug.
11. Installed dry hole marker.
12. Cleaned location and abandoned well.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>Joe T. [Signature]</u>	TITLE <u>Agent</u>	DATE <u>January 10, 1976</u>
APPROVED BY _____	TITLE _____	DATE _____
CONDITIONS OF APPROVAL, IF ANY:		