

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO. 30-025-27407
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. LG-987
7. Lease Name or Unit Agreement Name E. Hat Mesa State Unit
8. Well No. 1
9. Pool name or Wildcat Hat Mesa (Morrow)

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)	
1. Type of Well: OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER	
2. Name of Operator Barbara Fasken	
3. Address of Operator 303 W. Wall, Suite 1900, Midland, TX 79701	
4. Well Location Unit Letter F : 1980 Feet From The North Line and 1980 Feet From The West Line Section 7 Township 21-S Range 33-E NMPM Lea County	
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 3772' GR	

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐
PULL OR ALTER CASING ☐
OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐
COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐
CASING TEST AND CEMENT JOB ☐
OTHER: ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Kill well. ND wellhead. NU BOP.
2. Release packer. POW w/2-3/8" tubing and packer.
3. Set CIBP @ 13,700' by wireline.
4. RIW w/2-3/8" tubing open ended to 13,700'. Displace well with 9.5 ppg salt mud.
5. Spot 20 sx Class "H" cement on CIBP @ 13,700'. POW w/tubing.
6. Cut 5-1/2" casing and pull approximately 10,000' 5-1/2" casing.
7. RIW with tubing to casing stub. Tag this plug.
8. Spot 35 sx Class "C" cement @ 5688' for 9-5/8" shoe plug.
9. Spot 35 sx Class "C" cement @ 1650' for salt plug.
10. Set 10 sx Class "C" cement at surface.
11. Cut off casing 3' below ground level. Install cap plate and dry hole marker.
12. Remove mast anchors, clean location.

*SINCE THIS WELL IS IN THE POTASH AREA
YOU WILL NEED A SOLID CEMENT PLUG
THRU THE SALT SECTION (SALT CEMENT)
SEE RULE P-111*

THE COMMISSION MUST BE NOTIFIED 24
HOURS PRIOR TO THE BEGINNING OF
PLACING OPERATIONS FOR THE C-103
TO BE APPROVED.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Carl Brown TITLE Petroleum Engineer DATE 6-28-94
TYPE OR PRINT NAME TELEPHONE NO.

(This space for State Use)

APPROVED BY _____ TITLE DISTRICT I SUPERVISOR DATE JUL 01 1994

CONDITIONS OF APPROVAL, IF ANY: