

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

SUBMIT IN TRIPLICATE
(Other instructions on
reverse side.)

Form approved.
Budget Bureau No. 1004-0135
Expires August 31, 1985

5. LEASE DESIGNATION AND SERIAL NO.
NM-22809

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL ☐ GAS WELL ☒ OTHER

2. NAME OF OPERATOR
GETTY OIL COMPANY

3. ADDRESS OF OPERATOR
P.O. Box 730, Hobbs, New Mexico 88240

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At surface

Unit Letter J, 2180 FSL & 1980 FEL

14. PERMIT NO. 15. ELEVATIONS (Show whether DF, RT, GR, etc.)
3640' GR

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME
N. Bilbrey 7 Federal

9. WELL NO.
1

10. FIELD AND POOL, OR WILDCAT
South Salt Lake Morrow

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

Sec. 7, T21S, R32E

12. COUNTY OR PARISH 13. STATE
Lea NM

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐ PULL OR ALTER CASING ☐
FRACTURE TREAT ☐ MULTIPLE COMPLETE ☐
SHOOT OR ACIDIZE ☐ ABANDON* ☐
REPAIR WELL ☐ CHANGE PLANS ☐
(Other) Plug back and perforate Morrow X

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐ REPAIRING WELL ☐
FRACTURE TREATMENT ☐ ALTERING CASING ☐
SHOOTING OR ACIDIZING ☐ ABANDONMENT* ☐
(Other) ☐

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

1. Rig up pulling unit.
2. Kill well w/2% KCL brine.
3. Remove wellhead and install BOP.
4. Pull tubing and Otis packer.
5. Rig up Welex and set CIBP at 13,950', run dump bailer and dump 35' cement on top, PBTD = 13,915'.
6. Run 4 1/2" Otis Perma-latch packer on 2 3/8" tubing to 13,515' and displace hole w/2% KCL fresh water, set packer.
7. Swab well down to 7500'.
8. Rig up Welex and perforate Morrow @ 13,841'-47' with 2 spf, 13 holes with 1 9/16" SSB II tubing gun.
9. Flow and/or swab well to test.
10. If flow is inadequate, acidize well.
11. Rig down and move off.

18. I hereby certify that the foregoing is true and correct

SIGNED Dale R. Crockett

TITLE Area Superintendent

DATE 9/26/84

(This space for Federal or State office use)

APPROVED BY
CONDITIONS OF APPROVAL, IF ANY:

TITLE

DATE 10/25/84

0+6-BLM-Carlsbad 1-Mr. J.A.-Midland
1-File, 1-Engr DBW.
1-Foreman CRM

*See Instructions on Reverse Side