

748-4585

Submit 3 Copies
to appropriate
District Office

State of New Mexico
Energy, Minerals and Natural Resources Department

Form C-103
Revised 1-1-89

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO. 30-025-33209
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. V-3594
7. Lease Name or Unit Agreement Name Alphabet Unit
8. Well No. 1
9. Pool name or Wildcat Grama Ridge Bone Springs, North

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/> REVISED SUNDRY
2. Name of Operator YATES PETROLEUM CORPORATION
3. Address of Operator 105 South 4th St., Artesia, NM 88210
4. Well Location Unit Letter <u>C</u> : <u>330</u> Feet From The <u>North</u> Line and <u>1650</u> Feet From The <u>West</u> Line Section <u>8</u> Township <u>21S</u> Range <u>34E</u> NMPM Lea County 10. Elevation (Show whether DF, RKB, RT, GR, etc.) <u>3718' GR</u>

11.

Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐
PULL OR ALTER CASING ☐
OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐
COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐
CASING TEST AND CEMENT JOB ☐
OTHER: ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Propose to plug and abandon as follows:

1. Nipple up BOP. Pick up retainer stinger and 5600' of 2-7/8" tubing. Circulate off top of retainer with fresh water. Sting into retainer and establish injection rate and pressure with fresh water.
2. Mix and pump 60 sacks Class C Neat cement. Displace with 30 bbls fresh water. Sting out of retainer. TOOH. Remove retainer stinger.
3. TIH with tubing to 1860'. Load casing with mud. Set a balanced 50 sack Class C cement plug from 1860-1760'. Use 1% CaCl2 added on fly.
4. TOOH with tubing to 590'. Load casing with mud. Set a balanced 50 sack Class C cement plug from 590-490'. Use 2% CaCl2 added on fly.
5. Set a 25 sack Class C cement plug at surface.
6. Install regulation abandonment marker.

SEE ATTACHED SHEET FOR LOG TOPS

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE

Rusty Klein
Rusty Klein

TITLE

Operations Technician

DATE

Nov. 10, 1998

TYPE OR PRINT NAME

TELEPHONE NO. 505/748-1471

(This space for State Use)

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

JAN 25 1999

TR

Jic