

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

## SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL <input type="checkbox"/> GAS <input type="checkbox"/> OTHER- <b>Water injection well</b>		7. Unit Agreement Name
2. Name of Operator <b>Atlantic Richfield Company</b>		8. Farm or Lease Name <b>Seven Rivers Queen Unit</b>
3. Address of Operator <b>P.O. Box 1710, Hobbs, New Mexico 88240</b>		9. Well No. <b>1</b>
4. Location of Well UNIT LETTER <b>A</b> <b>330'</b> FEET FROM THE <b>north</b> LINE AND <b>990</b> FEET FROM <b>east</b> LINE, SECTION <b>27</b> TOWNSHIP <b>22S</b> RANGE <b>36E</b> NMPM.		10. Field and Pool, or Wildcat <b>Eunice 7 Rivers Queen So.</b>
15. Elevation (Show whether DF, RT, GR, etc.) <b>3501' GR</b>		12. County <b>LEA</b>

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>
OTHER <b>acidize</b> <input checked="" type="checkbox"/>	OTHER <input type="checkbox"/>
PLUG AND ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Propose to acidize present perms 3726'-30', 3740'-48', 3752'-54', 3764'-70', 3780'-90', 3792'-98' to increase injection rate in the following manner:

- Shut well in, connect to tbg and pump 1000 gals 15% HCL LSTNE Acid. Shut down & let soak for 30 minutes.
- Pump 600 gals acid.
- Inject 600# rock salt.
- Pump 1000 gals 15% HCL LSTNE Acid.
- Inject 600# rock salt.
- Pump 1000 gals 15% HCL LSTNE Acid.
- Flush tbg & perms w/injection water.
- Connect up well head and return to water injection.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED *A. L. Honea* TITLE Sr. Dist. Prod. Supv/ DATE 6/10/75

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE \_\_\_\_\_

CONDITIONS OF APPROVAL, IF ANY: