

NEW MEXICO OIL CONSERVATION COMMISSION

Santa Fe, New Mexico

MISCELLANEOUS NOTICES

Submit this notice in TRIPLICATE to the District Office, Oil Conservation Commission, before the work specified is to begin. A copy will be returned to the sender on which will be given the approval, with any modifications considered advisable, or the rejection by the Commission or agent, of the plan submitted. The plan as approved should be followed, and work should not begin until approval is obtained. See additional instructions in the Rules and Regulations of the Commission.

Indicate Nature of Notice by Checking Below

NOTICE OF INTENTION TO CHANGE PLANS		NOTICE OF INTENTION TO TEMPORARILY ABANDON WELL		NOTICE OF INTENTION TO DRILL DEEPER	
NOTICE OF INTENTION TO PLUG WELL		NOTICE OF INTENTION TO PLUG BACK		NOTICE OF INTENTION TO SET LINER	
NOTICE OF INTENTION TO SQUEEZE		NOTICE OF INTENTION TO ACIDIZE		NOTICE OF INTENTION TO SHOOT (Nitro)	
NOTICE OF INTENTION TO GUN PERFORATE & Frac	X	NOTICE OF INTENTION (OTHER)		NOTICE OF INTENTION (OTHER)	

OIL CONSERVATION COMMISSION
SANTA FE, NEW MEXICOHobbs, New Mexico
(Place)March 2, 1962
(Date)

Gentlemen:

Following is a Notice of Intention to do certain work as described below at the.....

Sunray Mid-Continent Oil Company **A. Christmas** Well No. **1** in **N**
(Company or Operator) (Lease) (Unit)
SE $\frac{1}{4}$ **SW** $\frac{1}{4}$ of Sec. **1**, T. **22S**, R. **37E**, NMPM, **Paddock** Pool
(40-acre Subdivision)
Lee County.

FULL DETAILS OF PROPOSED PLAN OF WORK
(FOLLOW INSTRUCTIONS IN THE RULES AND REGULATIONS)

1. Move in pulling unit. Load hole with oil. Remove Imas Tree and install BOP.
2. Pull rods and pump. Lower tubing to check fill and pull tubing. Run bit and reverse out if necessary.
3. Run LW G-R Neutron log from TD to surface.
4. Perf Paddock sections approximately 5090-5150' 2 shots/ft.
5. Run Baker FB packer on 3 1/2" tubing and set @ approximately 5075'.
6. Frac Paddock perfs 5090-5150' with 20,000 gallons refined oil in 4 stages.
7. Leave well shut-in 24 hrs or until pressure bleeds off whichever is the shorter time. Pull 3 1/2" tubing and packer when pressure permits. Check sand fill. Reverse circ if necessary.
8. Run 2 3/8" tubing with seating nipple and mud anchor. Run rods and pump and put well back on production.

Approved....., 19.....
Except as follows:Approved
OIL CONSERVATION COMMISSION**Sunray Mid-Continent Oil Company**
Company or OperatorBy.....
R. E. Statton
Position.....
District Engineer
Send Communications regarding well to:By.....
Title.....Name..... **C. T. McClanahan**
Address..... **Box 126, Hobbs, New Mexico**