

NUMBER OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
TRANSPORTER	OIL GAS
PERORATION OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Santa Fe, New Mexico

HOBBS OFFICE O. C. C.

MISCELLANEOUS NOTICES 6 7 35 AM '63

returned to the Bureau on which will be given the approval, with any modifications considered advisable, or the rejection by the Commission or agent, of the plan submitted. The plan as approved should be followed, and work should not begin until approval is obtained. See additional instructions in the Rules and Regulations of the Commission.

Indicate Nature of Notice by Checking Below

NOTICE OF INTENTION TO CHANGE PLANS		NOTICE OF INTENTION TO TEMPORARILY ABANDON WELL		NOTICE OF INTENTION TO DRILL DEEPER	
NOTICE OF INTENTION TO PLUG WELL		NOTICE OF INTENTION TO PLUG BACK		NOTICE OF INTENTION TO SET LINER	
NOTICE OF INTENTION TO SQUEEZE		NOTICE OF INTENTION TO ACIDIZE	X	NOTICE OF INTENTION TO SHOOT (Nitro)	
NOTICE OF INTENTION TO GUN PERFORATE	X	NOTICE OF INTENTION (OTHER)		NOTICE OF INTENTION (OTHER)	

OIL CONSERVATION COMMISSION
SANTA FE, NEW MEXICO

Roswell, New Mexico

December 13, 1963

(Place)

(Date)

Gentlemen:

Following is a Notice of Intention to do certain work as described below at the.....

Shell Oil Company

Binewalt

Well No. 2

in C

(Company or Operator)

NE

NW

1/4 of Sec. 4

T. 22 S

R. 37 E

NMPM,

Drinkard(oil) & Tubb(gas)

(Unit)

Pool

(40-acre Subdivision)

Lea

County.

FULL DETAILS OF PROPOSED PLAN OF WORK

(FOLLOW INSTRUCTIONS IN THE RULES AND REGULATIONS)

1. Kill Tubb with oil.
2. Spot or squeeze 25 ax cement through tubing. (Reverse out excess cement.)
3. Pull tubing and WOC.
4. Drill out Model "D" packer at 6460' and cement to 6500' with oil. (Plug back to 6500' with sand if cement top is below 6520'.) Set CIBP at 6498'.
5. Perforate 6462-6467', 6470-6474', 6477-6483' with 2 JSPF using a casing gun and lubricator.
6. Run 2" tubing with packer @ 6430'. Treat 1000 gallons 15% BDA plus Fe additive.
7. Pull tubing and packer.
8. Fracture treat via 5" casing with 50,000 gallons lease oil plus 1#/gallon 20-40 Radioactive sand plus 1/20#/gallon Mark II Adomite.
9. Check for sand fill and clean out to CIBP with sand pump and run Radioactive tracer survey.
10. Set Model D packer with expendable plug at 6310'.
11. Run tubing and swab test Tubb. Pull tubing.
12. Run Production equipment and latch into Model D packer. Swab test Drinkard.

Approved....., 19.....
Except as follows:

Shell Oil Company

Original Signed by

By R. A. Lowery

R. A. LOWERY

Approved
OIL CONSERVATION COMMISSION

By

Title

Position District Exploitation Engineer

Send Communications regarding well to:

Name Shell Oil Company

Address Box 1858 Roswell, New Mexico