

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

OIL CONSERVATION DIVISION
P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease
State ☐ Fee ☒
5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT - 1" (FORM C-101) FOR SUCH PROPOSALS.)

1. Name of Operator Gulf Oil Corporation		7. Unit Agreement Name	
2. Address of Operator P. O. Box 670, Hobbs, NM 88240		8. Farm or Lease Name Rollon Brunson	
3. Location of Well UNIT LETTER <u>G</u> , <u>2086</u> FEET FROM THE <u>North</u> LINE AND <u>1874</u> FEET FROM THE <u>East</u> LINE, SECTION <u>10</u> TOWNSHIP <u>22S</u> RANGE <u>37E</u> NMPM.		9. Well No. 4	
15. Elevation (Show whether DF, RT, GR, etc.) 3416' GL		10. Field and Pool, or Wildcat Blinebry & Drinkard	
12. County Lea			

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <u>Repair Water Flow</u> <input checked="" type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	

7. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

POH with 2-3/8" tubing. Set RBP at 3200', cap with 10' + frac sand. Perforate 7" casing at 2825' with (4) 1/2" JH in a plane with 90° phasing. Establish circulation down 7" casing and out 7" - 9-5/8" annulus. Set cement retainer at 2750'; re-establish circulation. Cement with 500 sacks Class "C" cement + 2% CaCl₂. Pull out of retainer, reverse out excess cement. Drill up retainer and cement; pressure test casing to 500#. Circulate sand off RBP. Recover RBP. GIH with 2-3/8" tubing & packer; set packer at 6185'. Swab.

3. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>R.D. Patra</u>	TITLE <u>Area Engineer</u>	DATE <u>8-5-80</u>
APPROVED BY <u>[Signature]</u>	TITLE <u>SUPERVISOR DISTRICT</u>	DATE <u>AUG 6 1980</u>
CONDITIONS OF APPROVAL, IF ANY:		