NEW MEXICO OIL CONSERVATION COMMISSION Santa Fe, New Mexico

MISCELLANEOUS NOTICES

Submit this notice in TRIPLICATE to the District Office, Oil Conservation Commission, before the work specified is to begin. A copy will be returned to the sender on which will be given the approval, with any modifications considered advisable, or the rejection by the Commission or agent, of the plan submitted. The plan as approved should be followed, and work should not begin until approval is obtained. See addi-

tional instructions in the Rules and Regulations of the Commission. Indicate Nature of Notice by Checking Below NOTICE OF INTENTION NOTICE OF INTENTION TO Notice of Intention TC CHANGE PLANS TEMPORARILY ABANDON WELL TO DRILL DEEPER NOTICE OF INTENTION NOTICE OF INTENTION NOTICE OF INTENTION TO PLUG WELL TO PLUG BACK I TO SET LINER NOTICE OF INTENTION Notice of Intention NOTICE OF INTENTION I TO SQUEEZE I TO ACIDIZE то Sноот (Nitro) Notice of Intention Notice of Intention X Notice of Intention TO GUN PERFORATE (OTHER) (OTHER) OIL CONSERVATION COMMISSION October 24, 1962 Hobbs, New Mexico SANTA FE, NEW MEXICO (Place) (Date) Gentlemen: Following is a Notice of Intention to do certain work as described below at the...... Secony Mobil Oil Company, Inc. Brunson Argo ..Well No.....in....in (Company or Operator) 223 Brunson (40-acre Subdivision),NMPM., FULL DETAILS OF PROPOSED PLAN OF WORK (FOLLOW INSTRUCTIONS IN THE RULES AND REGULATIONS) Cag: 13 3/8" @ 302 w/300sx., 9 5/8" @ 2832! w/975 sx., 52" @ 7454! w/1095 sx. Perfs: 7430-7450 Prepose to pull tubing and run Frontier Perf. Co. Isotron collar log surface to 7454'. Set permanent bridge plug @ 5260' and dump 2 ax cement on top of bridge plug. Perferate 52" csg. in Paddeck some as indicated by leg. Run tubing and

Secony Mobil Oil Company, Inc. m CIBP W/ dense 1 so clase Ву..... Group Supervisor Position. Approved Send Communications regarding well to: OIL CONSERVATION COMMISSION Socony Mobil Oil Company, Inc. Name. Box 2406, Hobbs, New Maxice

Address

full bore pkr. to 5000'. Swb. dry and acidise perfs. w/500 gal 15% NE acid followed by 5000 gals of Emulsified acid (50% of 15% acid & 10% Kerosene). Use sufficient RCH ball sealers to plug 80-90% of holes. Swab test and attempt to

complete in Paddock some.

Title.