

REMEDIAL CEMENTING PROCEDURE
DANGLADE NO. 1
3300' FHL & 660' FWL
SEC. 13, T-22-S, R-37-E
BLINEBRY GAS FIELD
LEA COUNTY, NEW MEXICO

August 6, 1975

Page Three

8. RU reverse equipment. GIH w/bit and DC's on tubing and drill out retainer and cement. Test cemented perforations to 1000 psi. If cemented perforations won't hold 1000 psi, contact Midland Engineering.
9. Run tubing with RBP retrieving tool. Reverse sand off of RBP, displace drilling and workover fluids with 2% KCl water containing 1 gal./1000 gals. Morflo II, and pull RBP.
10. Run tubing, swab well to flow, and place on production.

MLS:cs

cc: West Area

W. C. Young