## STATE OF NEW MEXICO VERGY AND MIMIERALS DEPARTMENT

	1	
DISTRIBUTION		
SANTA PE		
FILE	-	
U.S.G.S.		
LAND OFFICE		1
OPERATOR		il

## OIL CONSERVATION DIVISION

Form	(-	101
Revis	e d	10-1-7

DISTRIBUTION P. G. BOX 2088	Revised 10-1-78
SANTA FE, NEW MEXICO 87501	KE113EQ 13-1-70
FILE	5a, Indic ite Type of Leuse
U.S. G.S.	Strie Fae X
LAND OFFICE	5. State Oil 6 Gas Lease No.
OPERATOR	5, Strie Cit. & Gus Leuse No.
	 ************************************
SUNDRY NOTICES AND REPORTS ON WELLS	
IDO NOT USE THIS FORM FUR PROPOSALS TO PRILE OR TO STEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "SPECICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPUSALS.)	
	7, Unit Agreement Same
OIL 648 OTHER.	
ame of Operator	8. Farm of Lease Lame
Gulf Oil Corporation	Hugh
ddress of Operator	9. Well No.
P. O. Box 670, Hobbs, NM 88240	2
ocation of Well	10. Field and Fool, or Wildcat
UNIT LETTER C 660 FEET FROM THE NORTH LINE AND 2080 FEET FROM	Paddock
UNIT LETTER FEET PROM THE	
West Line, Section 14 TOWNSHIP 22S RANGE 37E HMPM.	
THE LINE, SECTION TOWNSHIP RANGE NMPM.	
15. Elevation (Show a kether DF, RT, GR, etc.)	12. County
3356' GL	Lea ()
Check Appropriate Box To Indicate Nature of Notice, Report or Oth	er Data
	REPORT OF:
FORM REMEDIAL WORK PLUG AND ABANDON X REMEDIAL WORK	ALTERING CASING
PORABILY ABANDON COMMENCE DRILLING OPHS.	PLUG AND ABANDOHMENT
L OR ALTER CASING CASING TEST AND CEMENT JOB	<del></del>
OTHER	U
DTHER	
Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including	estimated date of starting any proposed
ωργά) SEE RULE 1103.	

Set CIBP at 5000', cap with 35' cement. Test CIBP to 500#. Load hole with abandonment mud. Spot 100' plug 3900'-3800' with 20 sacks Class "C" neat. Spot 200' plug 3378'-3178' with 40 sacks Class "C" neat. Determine freepoint of 7"casing. Cut off casing at least 10' above freepoint. POH with 7" casing. Spot plug 2900' to 50' above 7" casing stub with Class "C" neat. WOC. Tag plug. Perf 9-5/8" casing at 1300' with (4)  $\frac{1}{2}$ " 90° phased holes. Attempt to establish circulation. Set cement retainer at 1250'. Circulate cement to surface with 400 sacks Class "C" neat. Cap cement retainer with 10 sacks cement. Spot 100' plug 361'-261' with 40 sacks Class "C" neat. WOC. Tag plug. Spot 50' surface plug with 20 sacks Class "C" neat.

ORIGINAL SIGNED BY JERRY SEXTON DISTRICT I SUPERVISOR	Y   T   E		MAR 23 1983	
R.D. Otte		Area Engineer		3-21-8 <b>3</b>
certify that the information above is true and compl	ete to the bes	it of my knowledge and belief,		

MAR 23 1983 HOBBS OFFICE

•