State of New Mexico Form C-103 Submit 3 Copies To Appropriate District Office Energy, Minerals and Natural Resources Revised March 25, 1999 District I WELL API NO. 1625 N. French Dr., Hobbs, NM 87240 30-025-10265 District II OIL CONSERVATION DIVISION 811 South First, Artesia, NM 87210 5. Indicate Type of Lease 2040 South Pacheco District III 1000 Rio Brazos Rd., Aztec, NM 87410 STATE X Santa Fe, NM 87505 FEE District IV 6. State Oil & Gas Lease No. 2040 South Pacheco, Santa Fe, NM 87505 LC-058626-A SUNDRY NOTICES AND REPORTS ON WELLS 7. Lease Name or Unit Agreement Name: (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.) LANGLIE-MATTIX PENROSE SAND UNIT 1. Type of Well: TRACT 1 Oil Well X Gas Well Other 2. Name of Operator 8. Well No. Anadarko Petroleum Corp. 3. Address of Operator 9. Pool name or Wildcat P.O. Box 2497 Midland, TX 79702 LANGLIE-MATTIX SR QN GRBG 4. Well Location Unit Letter 330 SOUTH feet from the 330 line and feet from the WEST line Section 14 Township Range 37E **NMPM** LEA County 10. Elevation (Show whether DR, RKB, RT, GR, etc.) 3339' GL 11. Check Appropriate Box to Indicate, Nature of Notice, Report, or Other Data NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF: PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK ALTERING CASING **TEMPORARILY ABANDON CHANGE PLANS** COMMENCE DRILLING OPNS. PLUG AND X **ABANDONMENT PULL OR ALTER CASING MULTIPLE** CASING TEST AND COMPLETION **CEMENT JOB** OTHER: OTHER: 12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompilation. 1. MIRUPU. NU & TEST BOPE. POH W/TBG. RU WL. RIH W/CIBP TO 3350'. SPOT 25 SX CL C CMT ON CIBP. TAG CMT @ 3094'. (OCD WITNESSED TAG) CIRC HOLE W/MUD. TOH W/TBG. 3. RU BWWC & PERF 4 SQUEEZE HOLES @ 2440'. TIH W/CR TO 2340' & SQZ W/50 SX CL C NEAT. DUMP 20' OF CMT ON CR. (BASE OF SALT) PERF @ 1230' W/4 SQUEEZE HOLES. TIH W/CR TO 1130' & SQZ W/90 SX CL C. CIRC 120 SX FROM 1130' TO SURFACE INSIDE 5-1/2" CSG. (TOP OF SALT) TOP OFF W/50 SX CMT. TAG CMT INSIDE 5-1/2" CSG @ 86' FROM SURF. CUT OFF WH. FILL CSG W/CMT TO SURFACE. INSTALL P&A MARKER, CUT OFF ANCHORS, CLEAN LOCATION. * GPS COORDINATES LAT 32 DEG. 23' 08.0" N LONG 103 DEG, 08' 27.5" W I hereby certify that the information above is true and complete to the best of my knowledge and belief. SIGNATURE. TITLE ENGR TECH III 03/29/01 _DATE_ Type or print name SABRA WOODY Telephone No. 915/683-0534 (This space for State use) APPROVED BY DATE Conditions of approval, if any: 106 GWW

M