

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TRIPlicate
(Other Instructions on
reverse side)Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

AC 064427

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. UNIT AGREEMENT NAME
2. NAME OF OPERATOR EXXON CORPORATION	8. FARM OR LEASE NAME PADDOCK UNIT
3. ADDRESS OF OPERATOR P.O. BOX 1600, MIDLAND TEXAS 79701	9. WELL NO. 98
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface 1980' FNL AND 660' FEL, SECTION 15, TOWNSHIP 22-S, RANGE 37-E.	10. FIELD AND POOL, OR WILDCAT PADDOCK
14. PERMIT NO.	11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA SEC. 15, 22-S, 37-E
15. ELEVATIONS (Show whether DF, RT, GR, etc.) 3388 DF	12. COUNTY OR PARISH LEA
	13. STATE NEW MEXICO

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

☐
☐
☐
☐

PULL OR ALTER CASING

☐
☐
☒
☐

FRACTURE TREAT

MULTIPLE COMPLETE

SHOOT OR ACIDIZE

ABANDON*

REPAIR WELL

CHANGE PLANS

(Other)

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

☐
☐
☐
☐

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

☐
☐
☐
☐

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

PLUG AND ABANDON PROCEDURE. CIRCULATE HOLE W/MUD
CONSISTING OF 25 SX GEL/100 BBLS. 9.5# BRINE. PUMP ALL PLUGS
DOWN W/MUD, AND TAG TOPS OF ALL PLUGS W/PIPE.
SPOT A 25/SX CL.H CEMENT PLUG FROM THE B.P. AT 5110' TO ABOUT
4950' (ACROSS THE PERFS AND 100' ABOVE).
DETERMINE FREE POINT, CUT OFF AND PULL 5 1/2" CSC AT ABOUT
4400' (CALC. TOP).
SPOT 100 FT. CL.H CEMENT PLUGS ACROSS THE 5 1/2" CSC. CUT (25 SX)
AND THE 8 5/8" CSC. SHOE AT 2776' (34 SX). (NOTE: TOP OF GLORIETA
IS AT 5020').
DETERMINE FREE POINT, CUT OFF AND PULL 8 5/8" CSC AT ABOUT 705'.
SPOT 100 FT CL.H CEMENT PLUGS ACROSS THE 8 5/8" CSC. CUT (57 SX)
AND THE 13 3/8" CSC. SHOE (84 SX).
SPOT A 10 SX CL.H CEMENT PLUG AT THE SURFACE.
SET WELL MARKER AND CLEAN UP LOCATION.

SEE REVERSE SIDE FOR AMENDMENTS:

18. I hereby certify that the foregoing is true and correct

SIGNED

A. L. Clemmer

TITLE

UNIT HEAD

DATE


10-9-75

(This space for Federal or State office use)

APPROVED BY

TITLE

CONDITIONS OF APPROVAL, IF ANY:



*See Instructions on Reverse Side

AMENDMENTS:

1. Cement plug at 5½" casing stub should be 35 sacks.
2. Place additional 150 sack cement plug in interval 3100-3600 if 5½" casing is pulled from below 3600 feet.
3. Cement plug at 8-5/8" stub should be 70 sacks.
4. Bottom plug and plug in interval 3100-3600 feet should be tagged to verify proper location.
5. If 5½" casing is not pulled below 3600 feet a cement plug is to be placed inside and outside 5½" casing through the interval 3100-3600 feet.