

COPIES RECEIVED	
DISTRIBUTION	
DATE	
BY	
LAND OFFICE	
OPERATOR	

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease
State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.
<b>B-934</b>

## SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Indicate Type of Well	2. Name of Operator	3. Address of Operator	4. Location of Well	5. Elevation (Show whether DF, RT, GR, etc.)	6. Unit Agreement Name	7. Farm or Lease Name	8. Well No.	9. Field and Pool, or Wildcat	10. County
OIL <input type="checkbox"/> GAS <input checked="" type="checkbox"/> OTHER <input type="checkbox"/>	<b>Wood, McShane &amp; Thams-692, Limited</b>	<b>P. O. Box 968, Monahans, Texas 79756</b>	UNIT LETTER <b>M</b> <b>660</b> FEET FROM THE <b>South</b> LINE AND <b>660</b> FEET FROM <b>West</b> LINE, SECTION <b>17</b> TOWNSHIP <b>22-S</b> RANGE <b>37-E</b> NMPM.	<b>3403' (DF)</b>	<b>---</b>	<b>New Mexico "M" State</b>	<b>12</b>	<b>Eumont</b>	<b>Lea</b>

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input checked="" type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input checked="" type="checkbox"/> <b>Recomplete in new reservoir</b>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- Kill well and pull tubing
- Perforate Yates and 7-Rivers from 2606'-3214' with 21-3/8" holes.
- Acidize with 1500 gals. acid.
- Frac perforated interval with 30,000 gals. gelled brine and 45,000# 20-40 sand.
- Put well back on production.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u><b>R. D. Inguch</b></u>	TITLE <u><b>Petroleum Engineer</b></u>	DATE <u><b>7-6-73</b></u>
APPROVED BY <u>                    </u>	TITLE <u>                    </u>	DATE <u>                    </u>
CONDITIONS OF APPROVAL, IF ANY:		