

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <input type="checkbox"/>		7. Unit Agreement Name
2. Name of Operator Amerada Hess Corporation		8. Farm or Lease Name E. Wood
3. Address of Operator Drawer "D", Monument, New Mexico 88265		9. Well No. 10
4. Location of Well UNIT LETTER <u>H</u> <u>1880</u> FEET FROM THE <u>North</u> LINE AND <u>860</u> FEET FROM THE <u>East</u> LINE, SECTION <u>22</u> TOWNSHIP <u>22-S</u> RANGE <u>37-E</u> NMPM.		10. Field and Pool, or Wildcat Drinkard
15. Elevation (Show whether DF, RT, GR, etc.)		12. County Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data			
NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input checked="" type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Plan to: Pull tubing. Set CIBP at 6330' with 10' cement on top. Set Ret. BP at 3650' with sand on top. Perforate 5-1/2" casing with 2 holes at 3425'. Squeeze holes with 200 sx. Class "C" cement as per Order No. R-5003. Run temperature survey. Drill out cement, test squeeze and recover ret. BP. Perforate Drinkard zone as per logs. Acidize with 15% NE acid. Frac if necessary. Set Baker Model "D" packer above Drinkard zone perms. Run 2-3/8" tubing with sliding sleeve. Produce Blinbry zone from annulus and Drinkard zone thru tubing. THE COMMISSION MUST BE NOTIFIED 14 DAYS BEFORE ~~STARTING~~ STARTING WORK ~~CASING~~.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.			
SIGNED <u>[Signature]</u>	TITLE <u>Supver., Admin. Services</u>	DATE <u>5-27-75</u>	
APPROVED BY _____	TITLE _____	DATE _____	
CONDITIONS OF APPROVAL, IF ANY:			