

Submit 3 Copies To Appropriate District  
Office  
District I  
1625 N. French Dr., Hobbs, NM 87240  
District II  
811 South First, Artesia, NM 87210  
District III  
1600 Rio Brazos Rd., Aztec, NM 87410  
District IV  
2040 South Pacheco, Santa Fe, NM 87505

State of New Mexico  
Energy, Minerals and Natural Resources

Form C-103  
Revised March 25, 1999

OIL CONSERVATION DIVISION  
2040 South Pacheco  
Santa Fe, NM 87505

WELL API NO. 30-025-10460
5. Indicate Type of Lease STATE <input type="checkbox"/> FEE <input checked="" type="checkbox"/>
6. State Oil & Gas Lease No.
7. Lease Name or Unit Agreement Name: M.W. COLL (FORMERLY LANGLIE MATTIX PENROSE SAND UNIT #18-1)
8. Well No. 1
9. Pool name or Wildcat LANGLIE-MATTIX SR ON GRBG

SUNDRY NOTICES AND REPORTS ON WELLS  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A  
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH  
PROPOSALS.)

1. Type of Well: Oil Well <input checked="" type="checkbox"/> Gas Well <input type="checkbox"/> Other	2. Name of Operator Anadarko Petroleum Corp.
3. Address of Operator P.O. Box 2497 Midland, TX 79702	4. Well Location Unit Letter M : 890 feet from the SOUTH line and 330 feet from the EAST line Section 26 Township 22S Range 37E NMPM LEA County
10. Elevation (Show whether DR, RKB, RT, GR, etc.) 3326' GR	

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

- PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒  
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐  
PULL OR ALTER CASING ☐ MULTIPLE COMPLETION ☐

OTHER: ☐

SUBSEQUENT REPORT OF:

- REMEDIAL WORK ☐ ALTERING CASING ☐  
COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐  
CASING TEST AND CEMENT JOB ☐

OTHER: ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

1. MIRUPU. KILL WELL. NDWH. NU BOPE.
2. SET CIBP @ 3100'. DUMP 10 SX CMT ON CIBP. WOC & TAG PLUG. PUH 10' AND CIRC HOLE W/MUD.
3. PUMP 50 SX PLUG @ 2550'. (BASE OF SALT)
4. PERF CSG @ 1275'. RIH W/CR TO 1125'. SQZ W/100 SX. DUMP 10 SX ON CR. (TOP OF SALT) - TAG
5. PERF CSG @ 220'. PUMP 100 SX AND CIRCULATE TO SURFACE.
6. FILL CSG WITH CMT TO SURFACE. CUT OFF & INSTALL P&A MARKER.

THE COMMISSION MUST BE NOTIFIED 24  
HOURS PRIOR TO THE BEGINNING OF  
PLUGGING OPERATIONS FOR THE C-103  
TO BE APPROVED.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE SABRA WOODY TITLE ENGR TECH III DATE 05/14/01

Type or print name SABRA WOODY Telephone No. 915/683-0534

(This space for State use)

APPROVED BY ORIGINAL SIGNED BY DATE MAY 27 2001  
Conditions of approval, if any: