

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

| | |
|------------------------|--|
| NO. OF COPIES RECEIVED | |
| DISTRIBUTION | |
| SANTA FE | |
| FILE | |
| U.S.O.S. | |
| LAND OFFICE | |
| OPERATOR | |

OIL CONSERVATION DIVISION

P. O. BOX 2088

SANTA FE, NEW MEXICO 87501

0+6-NM0CD-_____ 1-File

2-Midland-_____ 1-Engr. PJB

1-Foreman-_____

Form C-103
Revised 10-1-7

5a. Indicate Type of Lease

State ☐

Fee ☒

5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

| | |
|---|--|
| 1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- 2. Name of Operator Getty Oil Company 3. Address of Operator P.O. Box 730, Hobbs, New Mexico 88240 4. Location of Well UNIT LETTER <u>E</u> <u>1650</u> FEET FROM THE <u>North</u> LINE AND <u>990</u> FEET FROM <u>West</u> LINE, SECTION <u>26</u> TOWNSHIP <u>22S</u> RANGE <u>37E</u> NMPM. 15. Elevation (Show whether DF, RT, GR, etc.) <u>3339' DF</u> | 7. Unit Agreement Name 8. Farm or Lease Name Baker A 9. Well No. 5 10. Field and Pool, or Wildcat Undesignated Blinbry Oil and Gas 12. County Lea |
|---|--|

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐
TEMPORARILY ABANDON ☐
PULL OR ALTER CASING ☐
OTHER ☐

PLUG AND ABANDON ☒
CHANGE PLANS ☐
OTHER ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐
COMMENCE DRILLING OPNS. ☐
CASING TEST AND CEMENT JOBS ☐
OTHER ☐

ALTERING CASING ☐
PLUG AND ABANDONMENT ☒

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Rig up pulling unit and install BOP.
2. GIH with a mule shoe and kick sub on 2-7/8" workstring.
3. Run in hole to parted casing at $\pm 2945'$.
4. Work shoe and kick sub until it passes through the parted section at $\pm 2945'$.
Make several attempts with various tools if needed.
5. Once through the parted section, go down and tag fish at $\pm 4098'$.
6. Pull off and place a 100 sx. cement plug from $\pm 4000'$ to $3000'$.
7. POH with workstring.
8. GIH with CIBP on workstring.
9. Set CIBP above parted section of 5-1/2" at $\pm 2900'$.
10. Spot 100' of cement on CIBP.
11. Pull up to $\pm 2425'$ and place a 100 sx. plug from $\pm 2425'$ to $1420'$.
12. Pull up to $\pm 1200'$ and place a 100 sx. plug from $\pm 1200'$ to $200'$.
13. Pull up and spot a 10 sx. plug at the surface.
14. POH and WOC.
15. Weld 1" steel plate over casing and install dry hole marker, P & A.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Dale R. Crockett

TITLE Area Superintendent

DATE 3/29/84

APPROVED BY _____

TITLE _____

DATE _____

CONDITIONS OF APPROVAL, IF ANY:

FOR RECORD ONLY

RECEIVED
APR 9 1984
O.C.D.
HIGGS OFFICE