

Submit 3 Copies To Appropriate District Office

District I

1625 N. French Dr., Hobbs, NM 88240

District II

1301 W. Grand Avenue, Artesia, NM 88210

District III

1000 Rio Brazos Rd., Aztec, NM 87410

District IV

1220 S. St. Francis Dr., Santa Fe, NM 87505

State of New Mexico  
Energy, Minerals and Natural Resources

OIL CONSERVATION DIVISION  
1220 South St. Francis Dr.  
Santa Fe, NM 87505

Form C-103

Revised March 25, 1999

WELL API NO.  
30-025-10517

5. Indicate Type of Lease

STATE ☒ FEE ☐

6. State Oil & Gas Lease No.

7. Lease Name or Unit Agreement Name:

New Mexico "M" State

SUNDRY NOTICES AND REPORTS ON WELLS  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:

Oil Well ☐ Gas Well ☐ Other Injection Well

2. Name of Operator

G P II Energy, Inc.

3. Well No.

34

3. Address of Operator

PO Box 50682, Midland, TX 79710

9. Pool name or Wildcat

Langlie Mattix 7R-Qn-Grbrg

4. Well Location

Unit Letter D 660 feet from the North line and 660 feet from the West line

Section 29

Township 22S

Range 37E

NMPM

County

10. Elevation (Show whether DR, RKB, RT, GR, etc.)  
GR 3382'

11. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒

TEMPORARILY ABANDON ☐ CHANGE PLANS ☐

PULL OR ALTER CASING ☐ MULTIPLE COMPLETION ☐

OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐

COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐

CASING TEST AND CEMENT JOB ☐

OTHER: ☐

12. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompilation.

Plug and Abandon when rig is available.

See attached Schematic and Plugging Procedure.

THE COMMISSIONER OF THE STATE OF NEW MEXICO  
OFFICE OF THE ATTORNEY GENERAL  
1000 RIO BRAZOS RD., AZTEC, NM 87410  
TEL: 505/845-1000

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE

*Shawn Brown*

TITLE AGENT

DATE 2-13-03

Type or print name

Shawn Brown

Telephone No. 915 684-4748

(This space for State use)

APPROVED BY

ORIGINAL SIGNED BY  
GARY W. WINK

DATE

MAY 9 2003

Conditions of approval, if any:

OC FIELD REPRESENTATIVE II/STAFF MANAGER

## Squeeze and Plugging Procedures for the New Mexico "M" State #34

1. RUPU.
2. Install and test BOP.
3. Pressure up backside to 500# for 15<sup>Min.</sup> to check tubing - casing integrity. TOH with Packer.
4. GIH with wire line CIBP and set at approximately 3475'. GIH with bailer and dump 35' cement on CIBP.
5. GIH with tbg and packer to establish where the casing leak(s) is(are) located. Casing leaks are common in this area from 300' to 700'. Squeeze holes in casing with enough cement to bring the cement top behind the casing up to the top of the salt. WOC. Test casing to 500# for 15 minutes. TOH with packer.
6. GIH with tbg open ended and tag plug set above CIBP. PU and circulate hole with plugging mud. PU and pump ~~100' cement plug across~~ <sup>PERF</sup> 7" shoe, sufficient to bring plug 50'+ above top of shoe and 50'+ below 7" casing shoe. PU and WOC.
7. Tag plug set across 7" shoe. PU and set surface plug. — 60' OR 105X
8. Cut off casing and set dry hole marker.
9. Clean and remediate location.

Note: The NMOCD will be notified at least 24 hours before starting work on well.

\* SET 100' PLUG # / 1250' - 1150' TOP OF SALT


FILED  
5000  
000

GP II ENERGY, INC.  
NEW MEXICO "M" STATE #34  
660' FNL & 660' FWL  
SEC 29, T22S, R37E  
LEA COUNTY, NEW MEXICO

T.D. 3690'

### CURRENT

ELEVATION 3382'



### PROPOSED

ELEVATION 3382'

