

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

OIL CONSERVATION DIVISION
P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-71

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.O.B.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input checked="" type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER-	7. Unit Agreement Name LMPSU
2. Name of Operator Anadarko Petroleum Corporation	8. Farm or Lease Name Tract 29
3. Address of Operator P.O. Box 806 Eunice, New Mexico 88231	9. Well No. 1
4. Location of Well UNIT LETTER <u>I</u> <u>330</u> FEET FROM THE <u>East</u> LINE AND <u>1670</u> FEET FROM <u>South</u> THE LINE, SECTION <u>29</u> TOWNSHIP <u>22S</u> RANGE <u>37E</u> NMPM.	10. Field and Pool, or Wildcat Langlie Mattix-Penrose
15. Elevation (Show whether DF, RT, GR, etc.) N.A.	12. County Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPER. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>
OTHER <input type="checkbox"/>	OTHER <input type="checkbox"/>
PLUG AND ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. MIRUPU. TOH w/rods, pump, & tbq.
2. TIH w/RBP & PKR. Locate hole or holes. Dump 2 SX on top of RBP.
3. RU cementer & displace down csg 100 SX of recommended cement. WOC.
4. RURU TIH w/bit. Drill out cement inside csg. Test cement job. If it won't hold pressure; repeat squeeze. If it will hold pressure, TOH w/bit & TIH w/retrieving tool, circ sand from RBP & latch on to RBP & TOH.
5. TIH w/tbg, pump, & rods POP.
6. RDPUP

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

ISSUED <u>Howard W. Sexton</u>	TITLE <u>Field Foreman</u>	DATE <u>March 5, 1986</u>
ORIGINAL SIGNED BY JERRY SEXTON DISTRICT 1 SUPERVISOR	TITLE _____	DATE <u>MAR 7 - 1986</u>